

# **Operation and Maintenance Manual**



# CONTENTS

<b>1. Introduction</b>	<b>4</b>
Basic sets	6
<b>2. Technical data</b>	<b>14</b>
<b>3. Assembly instructions</b>	<b>14</b>
Assembly of the pneumatic cleaner in pictures	14
<b>4. Wiring instructions</b>	<b>18</b>
Wiring system for boiler running on pellets only without exhaust fan D14P, P14, P14/130, D21P, P21, D25P, P25, D15P, P15	20
Wiring diagram for only pellet boilers with exhaust fan D20P, D31P, D30P, D40P, D50P, P20, P31, P30, P40, P50	22
Wiring diagram for combined boilers for wood gasification and pellet burning DC18SP, DC25SP, DC30SPX, DC32SP, C18SP, C25SP, KC25S	24
Wiring diagram for combined boilers for wood gasification and pellet burning DC25GSP, DC30GSP	26
Wiring system for boiler running only on pellets without exhaust fan D10PX, PX10	28
Wiring system for boiler running only on pellets with exhaust fan D15PX, D20PX, D25PX, PX15, PX20, PX25	30
Wiring diagram for gasification boiler for wood, coal and briquettes equipped with exhaust fan with build-in burner in upper doors DCxxS(X), DCxxRS, CxxS(T), ACxxS, KCxxS - old version	32
Wiring diagram for gasification boiler for wood, coal and briquettes equipped with exhaust fan with build-in burner in upper doors DCxxS(X), DCxxRS, CxxS(T), ACxxS, KCxxS - Model from 2017 (2x AD03)	34
Adjusting and connecting wiring in boiler (not apply to DxxPX, PXxx)	37
Connecting compressor control via AD02 or AD03 module built in to boiler.	37
Connecting boiler exhaust fan control via AD03 module second terminal.	37
Compressor and solenoid valve (electrovalve) connection for boilers DxxPX, PXxx	38
Connecting the compressed air system	39
<b>5. Requirements for chimneys, flues and other boiler parts during operation with pneumatic burner cleaner</b>	<b>42</b>
Chimney	42
Flue way duct	42
Tubing between burner and conveyor, pellet inlet pipe with rim	42
Flaps for combustion air intake	43
Boiler exhaust fan, gasifier nozzle and gasifier grille	44
<b>6. Setting up the pneumatic burner cleaner</b>	<b>46</b>
Setting parameters	46
<b>7. Maintenance and cleaning of burner with combustion chamber pneumatic cleaner</b>	<b>50</b>
<b>WARRANTY PROVISIONS</b>	<b>53</b>

## 1. Introduction

The **pneumatic burner cleaner is an accessory** suitable for optimal **cleaning of the ATMOS A25 and A45 combustion chambers** when burning poorer quality wooden pellets which form cakes (ash clumps), i.e. wooden pellets with greater amounts of bark and dirt.



**WARNING** – This equipment does not deal with the burning of plant pellets, grains, other biological waste pressed into pellets or wooden pellets with greater content of the above mentioned substances.

The equipment ensures the automatic removal of clumps and ash from the burner combustion chamber at regular intervals, or always after the burner burns out. **The pneumatic burner cleaner is very fast, effective and reliable.**



**INFO** – **Pneumatic cleaning is not a replacement for regular servicing or where necessary the cleaning of the burner and boiler which has to be undertaken at regular intervals once every 7 to 90 days according to pellet quality.** The interval between checks and cleaning of the combustion chamber should be looked at taking account of the amount of foreign matter and dirt in the pellets, which can result in growth of apertures (holes) in the combustion chamber for intake of combustion air.

Combustion chamber cleaning is undertaken according to a preset program in the ATMOS A25 or ATMOS A45 burner electronics. Its frequency must always correspond to the quality of pellets burnt. **The poorer the pellet quality, the more frequent clumps must be removed from the combustion chamber.**



**INFO** - **Clumps of ash prevent combustion air from reaching the pellets**, meaning they cannot burn properly in the required time in the combustion chamber. This subsequently results in the overfilling of the combustion chamber and blockage of the pellet inlet pipe between the burner and conveyor.

**These ash clumps are not formed with high quality wooden pellets made of soft bark-free wood or other mixes of so-called white pellets**, meaning pneumatic cleaning is unnecessary. However, if it is built into the burner it saves us time, facilitates work, ensures consistent combustion quality, and thus reliability.

**The equipment works by day and night to ensure everything runs reliably.** The customer may, however, wish to ensure cleaning does not take place at night where the boiler is located, e.g. near to a bedroom. In this case, a **special 8 A timer** can be used to control the compressor directly by time (Note – this cannot normally be bought in shops)



**WARNING** – You should, however, be aware that if the pellet quality is so poor as to require burner cleaning at intervals shorter than can be set by the timer, the burner will not work reliably and the pellet inlet pipe will block.

The equipment is supplied as an accessory in sets according to boiler type



Basic set package with compressor



Opened set with modified compressor



Basic set package without compressor



Opened set without compressor



**INFO** - The difference between the set for A25 burner and A45 burner is only that the ignition coil board (holder), combustion chamber and pneumatic cleaning channel have different dimensions. Other parts are the same. For the set designed for amended boilers, where the burner is built in to the upper doors and boilers DxxPX, PXxx, the hose is 1.5 m, where all other versions have hose lengths of 1 m.



Compressor accessories for compressor use as a source of compressed air.

This accessory use, if we want the compressor to run independently for example to blow out inside of the burner.

Contents:

- pressure hose 2 m
- cable with 3-pin connector (female)

## Basic sets

### 1.1 CP25K set for A25 burner with compressor

code: H0520

for pellet boilers without exhaust fan

type: D14P, P14, P14/130, D21P, P21, D25P, P25, D15P, P15

#### Set contents:

- connecting air hose of length 1 m (diameter 28 mm) code: S0767
- complete screw fitting (3/4") with solenoid control and connecting cable code: S1036
- new ignition coil board (holder) for A25 burner code: H0277
- new combustion chamber for A25 burner code: H0276
- pneumatic cleaning channel with nut and washer code: H0533
- AD02 module (to affix to boiler) to control the compressor via R2 reserve outlet code: P0432
- 1500 W compressor with 6 l air receiver volume amended for pneumatic cleaning code: H0305
- connecting cable with 3-pin connector (female) between the compressor, boiler and wall socket code: S0747

### 1.2 CP25 set for A25 burner without compressor

code: H0521

for pellet boilers without exhaust fan

type: D14P, P14, P14/130, D21P, P21, D25P, P25, D15P, P15

#### Set contents:

- connecting air hose of length 1 m (diameter 28 mm) code: S0767
- complete screw fitting (3/4") with solenoid control and connecting cable code: S1036
- new ignition coil board (holder) for A25 burner code: H0277
- new combustion chamber for A25 burner code: H0276
- pneumatic cleaning channel with nut and washer code: H0533
- AD02 module (to affix to boiler) to control the compressor via R2 reserve outlet code: P0432
- connecting cable with 3-pin connector (female) between the compressor, boiler and wall socket code: S0747
- 3-pin connector (male) for powering and controlling other compressor (valve) code: S0647

**1.3 CP25KS set for A25 boiler with compressor**

code: H0524

**for pellet boilers and DCxxSP combined boilers with exhaust fan****type:** D20P, P20, DC18SP, DC25SP, DC30SPX, DC32SP, C18SP, C25SP, KC25SP**Set contents:****Set contents:**

- connecting air hose of length 1 m (diameter 28 mm) code: S0767
- complete screw fitting (3/4") with solenoid control and connecting cable code: S1036
- new ignition coil board (holder) for A25 burner code: H0277
- new combustion chamber for A25 burner code: H0276
- pneumatic cleaning channel with nut and washer code: H0533
- AD03 module (to affix to boiler) for controlling boiler exhaust fan from AD04 module through VV burner electronics terminal (15) and compressor through R2 reserve outlet code: P0436
- AD04 module (to affix to burner) for controlling boiler exhaust fan through AD03 module and VV burner electronics terminal code: P0446
- 1500 W compressor with 6 l air receiver volume amended for pneumatic cleaning code: H0305
- connecting cable with 3-pin connector (female) between the compressor, boiler and wall socket code: S0747

**1.4 CP25S set for A25 burner without compressor**

code: H0525

**for pellet boilers and DCxxSP combined boilers with exhaust fan****typ:** D20P, P20, DC18SP, DC25SP, DC30SPX, DC32SP, C18SP, C25SP, KC25SP**Set contents:**

- connecting air hose of length 1 m (diameter 28 mm) code: S0767
- complete screw fitting (3/4") with solenoid control and connecting cable code: S1036
- new ignition coil board (holder) for A25 burner code: H0277
- new combustion chamber for A25 burner code: H0276
- pneumatic cleaning channel with nut and washer code: H0533
- AD03 module (to affix to boiler) for controlling boiler exhaust fan from AD04 module through VV burner electronics terminal (15) and compressor through R2 reserve outlet code: P0436
- AD04 module (to affix to burner) for controlling boiler exhaust fan through AD03 module and VV burner electronics terminal code: P0446
- connecting cable with 3-pin connector (female) between the compressor, boiler and wall socket code: S0747
- 3-pin connector (male) for powering and controlling other compressor (valve) code: S0647

## 1.5 CP25KGSP set for A25 boiler with compressor for pellet boilers and DCxxGSP combined boilers with exhaust fan

code: H0544

type: DC25GSP, DC30GSP

### Set contents:

#### Set contents:

- connecting air hose of length 1 m (diameter 28 mm) code: S0767
- complete screw fitting (3/4") with solenoid control  
and connecting cable code: S1036
- new ignition coil board (holder) for A25 burner code: H0277
- new combustion chamber for A25 burner code: H0276
- pneumatic cleaning channel with nut and washer code: H0533
- AD02 module (to affix to boiler) for controlling boiler exhaust fan  
from AD04 module through VV burner electronics terminal (15) and compressor  
through R2 reserve outlet code: P0432
- 1500 W compressor with 6 l air receiver volume amended for  
pneumatic cleaning code: H0305
- connecting cable with 3-pin connector (female) between the compressor,  
boiler and wall socket code: S0747

## 1.6 CP25GSP set for A25 burner without compressor for pellet boilers and DCxxGSP combined boilers with exhaust fan

code: H0545

typ: DC25GSP, DC30GSP

### Set contents:

- connecting air hose of length 1 m (diameter 28 mm) code: S0767
- complete screw fitting (3/4") with solenoid control  
and connecting cable code: S1036
- new ignition coil board (holder) for A25 burner code: H0277
- new combustion chamber for A25 burner code: H0276
- pneumatic cleaning channel with nut and washer code: H0533
- AD02 module (to affix to boiler) for controlling boiler exhaust fan  
from AD04 module through VV burner electronics terminal (15) and compressor  
through R2 reserve outlet code: P0432
- connecting cable with 3-pin connector (female) between the compressor,  
boiler and wall socket code: S0747
- 3-pin connector (male) for powering and controlling other compressor (valve) code: S0647



## 1.7 CP45KS set for A45 burner with compressor

code: H0522

for pellet boilers with exhaust fan

type: D31P, D30P, D40P, D50P, P31, P30, P40, P50

### Set contents:

- connecting air hose of length 1 m (diameter 28 mm) code: S0767
- complete screw fitting (3/4") with solenoid control and connecting cable code: S1036
- new ignition coil board (holder) for A45 burner code: H0417
- new combustion chamber for A45 burner code: H0418
- pneumatic cleaning channel with nut and washer for A45 burner code: H0536
- AD03 module (to affix to boiler) for controlling boiler exhaust fan from AD04 module through VV burner electronics terminal (15) and compressor through R2 reserve outlet code: P0436
- AD04 module (to affix to burner) for controlling boiler exhaust fan through AD03 module and VV burner electronics terminal code: P0446
- 1500 W compressor with 6 l air receiver volume amended for pneumatic cleaning code: H0305
- connecting cable with 3-pin connector (female) between the compressor, boiler and wall socket code: S0747

## 1.8 CP45S set for A45 boiler without compressor

code: H0523

for pellet boilers with exhaust fan

type: D31P, D30P, D40P, D50P, P31, P30, P40, P50

### Set contents:

- connecting air hose of length 1 m (diameter 28 mm) code: S0767
- complete screw fitting (3/4") with solenoid control and connecting cable code: S1036
- new ignition coil board (holder) for A45 burner code: H0417
- new combustion chamber for A45 burner code: H0418
- pneumatic cleaning channel with nut and washer for A45 burner code: H0536
- AD03 module (to affix to boiler) for controlling boiler exhaust fan from AD04 module through VV burner electronics terminal (15) and compressor through R2 reserve outlet code: P0436
- AD04 module (to affix to burner) for controlling boiler exhaust fan through AD03 module and VV burner electronics terminal code: P0446
- connecting cable with 3-pin connector (female) between the compressor, boiler and wall socket code: S0747
- 3-pin connector (male) for powering and controlling other compressor (valve) code: S0647

**1.9 UCP25KS set for A25 burner with compressor**

code: H0526

**for gasification boilers for wood, coal and briquettes with built-in burner in upper doors****type:** DCxxS(X), DCxxRS, CxxS(T), ACxxS, KCxxS**Set contents:**

- connecting air hose of length 1,5 m (diameter 28 mm) code: S0768
- complete screw fitting (3/4") with solenoid control and connecting cable code: S1036
- new ignition coil board (holder) for A25 burner code: H0277
- new combustion chamber for A25 burner code: H0276
- pneumatic cleaning channel with nut and washer code: H0533
- AD03 module (to affix to boiler) for controlling boiler exhaust fan from AD04 module through VV burner electronics terminal (15) and compressor through R2 reserve outlet code: P0436
- AD04 module (to affix to burner) for controlling boiler exhaust fan through AD03 module and VV burner electronics terminal code: P0446
- 1500 W compressor with 6 l air receiver volume amended for pneumatic cleaning code: H0305
- connecting cable with 3-pin connector (female) between the compressor, boiler and wall socket code: S0747
- additional grille code: H0534
- special valve (mechanism for closing space under flap controlled by FR 124 barometric damper (2 + 1 pcs.) code: H0535

**1.10 UCP25S set for A25 burner without compressor**

code: H0527

**for gasification boilers for wood, coal and briquettes with built-in burner in upper doors****type:** DCxxS(X), DCxxRS, CxxS(T), ACxxS, KCxxS**Set contents:**

- connecting air hose of length 1,5 m (diameter 28 mm) code: S0768
- complete screw fitting (3/4") with solenoid control and connecting cable code: S1036
- new ignition coil board (holder) for A25 burner code: H0277
- new combustion chamber for A25 burner code: H0276
- pneumatic cleaning channel with nut and washer code: H0533
- AD03 module (to affix to boiler) for controlling boiler exhaust fan from AD04 module through VV burner electronics terminal(15) and compressor through R2 reserve outlet code: P0436
- AD04 module (to affix to burner) for controlling boiler exhaust fan through AD03 module and VV burner electronics terminal code: P0446
- connecting cable with 3-pin connector (female) between the compressor, boiler and wall socket code: S0747
- 3-pin connector (male) for powering and controlling other compressor (valve) code: S0647
- additional grille code: H0534
- special valve (mechanism for closing space under flap controlled by FR 124 barometric damper (2 + 1 pcs.) code: H0535

**1.11 CPX25KS set for A25 boiler with compressor**

code: H0538

**for pellet boilers with exhaust fan****type:** D10PX, D15PX, D20PX, D25PX, PX10, PX15, PX20, PX25**Set contents:****Set contents:**

- connecting air hose of length 1,5 m (diameter 28 mm) code: S0768
- complete screw fitting (3/4") with solenoid control  
and connecting cable code: S1036
- new ignition coil board (holder) for A25 burner code: H0277
- new combustion chamber for A25 burner code: H0276
- pneumatic cleaning channel with nut and washer code: H0533
- 1500 W compressor with 6 l air receiver volume amended for  
pneumatic cleaning code: H0305
- connecting cable with 3-pin connector (female) between the compressor,  
boiler and wall socket code: S0747

**1.12 CPX25S set for A25 burner without compressor**

code: H0539

**for pellet boilers with exhaust fan****type:** D10PX, D15PX, D20PX, D25PX, PX10, PX15, PX20, PX25**Set contents:**

- connecting air hose of length 1,5 m (diameter 28 mm) code: S0768
- complete screw fitting (3/4") with solenoid control  
and connecting cable code: S1036
- new ignition coil board (holder) for A25 burner code: H0277
- new combustion chamber for A25 burner code: H0276
- pneumatic cleaning channel with nut and washer code: H0533
- connecting cable with 3-pin connector (female) between the compressor,  
boiler and wall socket code: S0747
- 3-pin connector (male) for powering and controlling other compressor (valve) code: S0647



Complete screw fitting (3/4") with solenoid control and connecting cable



New ignition coil board (holder) for A25 and A45 burners



New combustion chamber for A25 and A45 burner



Pneumatic cleaning channel with nut and washer for A25 and A45 burners



AD02, AD03 and AD04 modules (except DxxPX, PXxx)  
Connecting cable with 3-pin connector (female)  
and separate 3-pin connector (male)



Amended compressor for pneumatic cleaning



**INFO** - The basic set without compressor should be chosen only if you have a compressor of receiver volume from 5 to 10 l which can reach a pressure of 5 - 8 bar (500 - 800 kPa). The compressor or receiver must be right next to the boiler and the basic pipe diameters with which the air is pumped into the chamber must be kept.





**WARNING** - If air is pumped in from a greater distance, we must add a small receiver of 5 to 10 l volume near the boiler which will allow its hassle-free filling with compressed air of 5 to 8 bar (500 - 800 kPa). Larger receivers cannot be used. This second solenoid fitted to the compressed air pipe is deliberately located on the compressed air inlet into the additional receiver so that when cleaning the burner with compressed air there is not additional flow (release) of compressed air into the additional receiver. We install a reduction valve in front of the additional solenoid for setting the optimum pressure for the pneumatic burner cleaner (5 bar/500 kPa). The second valve must be controlled in the same way as the separate compressor, through output R2 through the AD03 or AD02 module.



**WARNING** - Cleaning the burner using compressed air flowing directly from a central compressed air supply or from a receiver of greater than 10 l volume is strictly forbidden.

EN

Connection diagram with additional receiver and second solenoid



For boilers D14P, P14, P14/130, D21P, P21, D25P, P25, D15P, P15  
D10PX, PX10 (without AD02)

For boilers D20P, D30P, D40P, D50P, D31P, P20, P30, P40, P50, P31, DCxxSP(X), CxxSP, KCxxSP, DCxxGSP, boilers with modification for burner - DCxxS(X), DCxxRS, CxxS(T), ACxxS, KCxxS

D15PX, D20PX, D25PX, PX15, PX20, PX25 (without AD03)

## 2. Technical data

**Name:** Pneumatic burner cleaner - accessory

**Prescribed burner:** ATMOS A25 and A45 AC07X models or higher

**Power supply:** 230 V / 50 Hz

**Maximum power when using supplied compressor:** 1500 W

**Maximum power when using other equipment:** according to equipment type

**Control of functions:** electronic regulation of burner AC07X, controlling both burner pneumatic cleaning and burner operations. Function using both reserve outlets R and R2, which thus cannot be used for other purposes.

**Profiles:** A25, A25 pneu, A25 GSP, A25 GSP pneu, A25PX, A25PX pneu, A45, A45 pneu

Other necessary information is included in the burner manual and manual for your specific boiler.


**Pneumatic cleaner operating pressure:** 2 - 8 bar (200 - 800 kPa)

## 3. Assembly instructions




**WARNING – pneumatic cleaner assembly may only be undertaken by a qualified person trained by the manufacturer in accordance with rules and regulations in force.** Before running, you must familiarise yourself completely with the operation manual. You must also observe all general safety regulations for working with heating equipment and pressure vessels which are given by laws in force.

### Assembly of the pneumatic cleaner in pictures



*First place the burner on a table or hard surface and remove the old combustion chamber*




*Loosen the M6 screws which hold the ignition coil board*




*Loosen and screw out the M6 screw which holds the burner nozzle cover and remove the cover*



*Screw out the M6 screws which hold the ignition coil board*




*Disconnect the ignition coil connectors and frame, remove the board*



*Disassemble the ignition coils*



**INFO** – the old combustion chamber and ignition coil board will no longer be used.



Take the new ignition coil board and put it together again in the same way (screw together)



Disassemble seal cover located on the lower section of the burner



**WARNING** – when assembling, ensure the **ignition coils evenly cover the holes where the pellets and ignition bodies come into contact.** Tighten firmly.



**WARNING** – for old burners which do not have a preprepared opening for pneumatic burner cleaning, holes for screws must be drilled according to product. The product is supplied in an general model (one product) for small or large burners separately or with graduated drill.

**Set for drilling aperture into body of older burner**

code: S0623

The set is made up of a graduated drill for **drilling a  $\text{Ø } 27 \pm 1 \text{ mm}$**  hole and product for predrilling a basic aperture in the burner body.

**Separate general product for predrilling aperture in burner body**

code: S0610



Screw the original screws back into the holes so air cannot flow through them or false air be sucked through them



Set the pneumatic cleaning channel in the burner and gently secure using washer and low nut





*Insert the new board for holding the ignition coils into the burner while securely affixing the frame (green-yellow wire) under one of the nuts*



*Mount connectors to every ignition coil (white and blue always together on one ignition body)*



*Insert ignition coil board in its place and centre the pneumatic cleaning channel in its designated place*



*Carefully tighten the nuts with washers to the burner body*



*Insert new combustion chamber and check everything once again, tightening where needed*



*Take complete screw fitting with solenoid control and connecting cable and screw it to the burner*



**INFO** – the burner combustion chamber must fit freely into the burner, and the pneumatic cleaning channel must be centred so that there is equal give along its sides.

## 4. Wiring instructions



**WARNING** - Wiring may only be undertaken by a **qualified person in accordance with all rules and regulations of your country** with careful attention paid to ensuring the safe earthing of the boiler and burner.

**Connecting the solenoid valve control directly to the burner terminal (reserve R) or module AC07X-C**



**INFO** - if the boiler is without an exhaust fan or boiler DCxxGSP, carefully insulate the unconnected grey wire; for boilers with exhaust fans, the grey wire will be used (**not apply to DxxPX, PXxx**).



*Pull the solenoid valve (electrovalve) connecting cable using the grommet through the brake down hole in the lower part of the burner body*



*From the burner terminal plate, disconnect the grey wire from terminal R (9), connect the brown wire from the solenoid valve to terminal R (9) and the blue wire to terminal N (8) (**not apply to Dxx-PX, PXxx**)*




*For models DxxPX and PXxx connect solenoid valve (electrovalve) into the AC07X-C module. Blue wire N to terminal (4) and brown wire L to terminal R6 (6)*



*Connect the green and yellow wire with eyelet to the common frame on the burner body*

# Wiring system for boiler running on pellets only without exhaust fan D14P, P14, P14/130, D21P, P21, D25P, P25, D15P, P15



**WHEN USE ELECTRONIC REGULATION ACD01 AND PELLETBURNER A25-45 MUST BE THESE CHANGES OF WIRING:  
 BEI DER STEUERUNG DES KESSELBETRIEBES DER ELEKTRONISCHE REGELUNG ACD01 UND PELLETBRENNER A25-45 MÜSSEN DIESE ÄNDERUNGEN MACHEN SEIN:  
 PŘI ZAPOJENÍ ELEKTRONICKÉ REGULACE ACD01 A PELETOVÉHO HOŘÁKU A25-45 PŘEDVĚDTE TYTO ZMĚNY:**


- (A)** VARIANTS OF RESERVOIR POINTS "REG L,N,PE" (FERRULE/FASTON 6,3) FOR ELECTRONIC REGULATION SPEISEKLEMMENVARIANTEN "REG L,N,PE" (ADERENDHÜLSE/FASTON 6,3) FÜR ELEKTRONISCHE REGELUNG VARIANTEN NÄPAJEČÍCH SVOREK "REG L,N,PE" (DUTINKA/FASTON 6,3) PRO ELEKTRONICKOU REGULACI
- (B)** RESERVOIR POINT "L2 OUT" OF BURNER AND FAN TO THE ELECTRONIC REGULATION (ACD01) SPEISEKLEMME "L2 OUT" DER BRENNER UND VENTILATOR FÜR DIE ELEKTRONISCHE REGELUNG (ACD01) PŘIPOJOVACÍ SVORKA "L2 OUT" HOŘÁKU A VENTILÁTORU DO ELEKTRONICKÉ REGULACE (ACD01)
- (C)** RESERVOIR POINT "L PUMP" OF BOILER PUMP TO THE ELECTRONIC REGULATION (ACD01) SPEISEKLEMME "L PUMP" DER KESSELPUMPE FÜR DIE ELEKTRONISCHE REGELUNG (ACD01) PŘIPOJOVACÍ SVORKA "L PUMP" KOTLOVÉHO ČERPADLA DO ELEKTRONICKÉ REGULACE (ACD01)
- (D)** WHEN ELECTRONIC REGULATION CONTROL BURNER - CONNECTOR "PT-C" MUST BE UNCONNECT DEN KONNEKTOR "PT-C" ABKLEMMEN BEI DER BRENNERBEDIENUNG DER ELEKTRONISCHE REGELUNG KONNEKTOR "PT-C" ODPJOJIT PŘI OVLÁDÁNÍ HOŘÁKU ELEKTRONICKOU REGULACÍ
- (E)** WHEN ELECTRONIC REGULATION CONTROL BOILER PUMP - CONNECTOR "TC-2" MUST BE UNCONNECT DEN KONNEKTOR "TC-2" ABKLEMMEN BEI DER KESSELPUMPEBEDIENUNG DER ELEKTRONISCHE REGELUNG KONNEKTOR "TC-2" ODPJOJIT PŘI OVLÁDÁNÍ KOTLOVÉHO ČERPADLA ELEKTRONICKOU REGULACÍ
- (F)** ACCES POINT FOR EXTERNAL BOILERREGULATION - PLUG IN CONNEKTOR ANLAGERUNG FÜR EXTERN KESSELREGELUNG - KLEMMEN IN DEN KONNEKTOR PŘIPOJOVACÍ SVORKY PRO EXTERNÍ REGULACI KOTLE - KLEMA V KONNEKTORU
- (G)** CONNECTOR (BLACK/RED) - FOR EXAMPLE RESERVOIS POINT FOR MODUL AD01 - MOTOR OF ASH-REMOVER KONNEKTOR (SCHWARZ/ROT) - ZUM BEISPIEL FÜR DEN MODUL AD01 - MOTOR ENTSCHEUNGMOTOR KONNEKTOR (ČERNO ČERVENÝ) - NAPŘÍKLAD PRO MODUL AD01 - MOTOR ODPPELNĚNÍ
- (H)** ACCES POINTS - FOR EXAMPLE FOR MODUL AD01 - TIMEUNIT OF ASH-REMOVER SPEISEKLEMME - ZUM BEISPELE FÜR MODUL AD01 - ZEITBEDIENUNG FÜR DEN ENTSCHEUNGMOTOR ODPPELNĚNÍ - NAPŘÍKLAD PRO MODUL AD01 - ČASOVÝ MODUL ODPPELNĚNÍ
- (I)** MODUL AD02 FOR CONTROL COMPRESSOR FROM BURNER A25/45 MODUL AD02 FÜR BREMSKOMPRESSORBEDIENUNG BEI DEM BRENNER A25/45 MODUL AD02 K OVLÁDÁNÍ KOMPRESSORU HOŘÁKEM A25/45

15-01-01\_D14-25P\_A25-45


**FOR BOILER:  
 FÜR KESSEL:  
 PRO KOTLE:**

- D14P
- D15P
- D21P
- D25P
- P14,P15
- P14/130
- P21
- P25


**ELECTRIC DIAGRAM OF BRENNER A25-45 BEFORE IN-BUILDING PNEUMATIC CLEARING**  
**BRENNER A25-45 LEITUNGSSCHEMA VOR PNEUMATICREINIGUNGSMONTAGE**  
**ELEKTRICKÉ SCHÉMA HOŘÁKU A25-45 PŘED VESTAVBOU PNEUMATICKÉHO ČIŠTĚNÍ**



**ELECTRIC DIAGRAM OF BRENNER A25-45 AFTER IN-BUILDING PNEUMATIC CLEARING**  
**BRENNER A25-45 LEITUNGSSCHEMA DANN PNEUMATICREINIGUNGSMONTAGE**  
**ELEKTRICKÉ SCHÉMA HOŘÁKU A25-45 PO VESTAVBĚ PNEUMATICKÉHO ČIŠTĚNÍ**



# Wiring diagram for only pellet boilers with exhaust fan D20P, D31P, D30P, D40P, D50P, P20, P31, P30, P40, P50



WHEN USE ELECTRONIC REGULATION ACD01 AND PELLETBURNER A25-45 MUST BE THESE CHANGES OF WIRING:  
 BEI DER STEUERUNG DES KESSELBETRIEBES DER ELEKTRONISCHE REGULATION ACD01 UND PELLETBRENNER A25-45 MÜSSEN DIESE ÄNDERUNGEN MACHEN SEIN:  
 PŘI ZAPOJENÍ ELEKTRONICKÉ REGULACE ACD01 A PELETOVÉHO HOŘÁKU A25-45 PŘEVEDTE TYTO ZMĚNY:

19-10-01\_D20-50P\_A25-45\_6P\_AD03

- A** VARIANTS OF RESERVOIR POINTS "REG L,N,PE" (FERRULE/FASTON 6,3) FOR ELECTRONIC REGULATION SPEISEKLEMMENVARIANTEN "REG L,N,PE" (ADERENDHÜLSE/FASTON 6,3) FÜR ELEKTRONISCHE REGULATION VARIANTI NAPÁJECÍCH SVORK (DUTINKA/FASTON 6,3) PRO ELEKTRONICKOU REGULACI
- B** RESERVOIR POINT "L2 OUT" OF BURNER AND FAN TO THE ELECTRONIC REGULATION (ACD01) SPEISEKLEMME "L2 OUT" DER BRENNER UND VENTILATOR FÜR DIE ELEKTRONISCHE REGULACE (ACD01) PŘÍPOJOVACÍ SVORKA "L2 OUT" HOŘÁKU A VENTILÁTORU DO ELEKTRONICKÉ REGULACE (ACD01)
- C** RESERVOIR POINT "L PUMP" OF BOILER PUMP TO THE ELECTRONIC REGULATION (ACD01) SPEISEKLEMME "L PUMP" DER KESSELPUMPE FÜR DIE ELEKTRONISCHE REGULACE (ACD01) PŘÍPOJOVACÍ SVORKA "L PUMP" KOTLOVÉHO ČERPADLA DO ELEKTRONICKÉ REGULACE (ACD01)
- D** WHEN ELECTRONIC REGULATION CONTROL BURNER - CONNECTOR "PT-C" MUST BE UNCONNECT DEN KONEKTOR "PT-C" ABKLEMMEN BEI DER BRENNERBEDIENUNG DER ELEKTRONISCHE REGULACE KONEKTOR "PT-C" ODPJOJIT PŘI OVLÁDÁNÍ HOŘÁKU ELEKTRONICKOU REGULACI
- E** WHEN ELECTRONIC REGULATION CONTROL BOILER PUMP - CONNECTOR "TC-2" MUST BE UNCONNECT DEN KONEKTOR "TC-2" ABKLEMMEN BEI DER KESSELPUMPEBEDIENUNG DER ELEKTRONISCHE REGULACE KONEKTOR "TC-2" ODPJOJIT PŘI OVLÁDÁNÍ KOTLOVÉHO ČERPADLA ELEKTRONICKOU REGULACI
- F** ACCESS POINT FOR EXTERNAL BOILERREGULATION - PLUG IN CONNECTOR ANLAGERUNG FÜR EXTERN KESSELREGULATION - KLEMME IN DEN KONEKTOR PŘÍPOJOVACÍ SVORKY PRO EXTERNI REGULACI KOTLE - KLEMA V KONEKTORU
- G** CONNECTOR (BLACK/RED) - FOR EXAMPLE RESERVOIS POINT FOR MODUL AD01 - MOTOR OF ASH-REMOVER KONEKTOR (SCHWARZ/ROT) - ZUM BEISPIEL FÜR DEN MODUL AD01 - ENTASCHUNGSMOTOR KONEKTOR (ČERNO ČERVENÝ) - NÁPŘÍKLAD PRO MODUL AD01 - MOTOR ODPPELNĚNÍ
- H** ACCESS POINTS - FOR EXAMPLE FOR MODUL AD01 - TIMEUNIT OF ASH-REMOVER SPEISEKLEMME - ZUM BEISPEILE FÜR MODUL AD01 - ZEITBEDIENUNG FÜR DEN ENTASCHUNG PŘÍPOJENÍ - NÁPŘÍKLAD PRO MODUL AD01 - ČASOVÝ MODUL ODPPELNĚNÍ
- I** SENSOR "TK" FOR BURNER A25 KESSEL WASSER FÜHLER "TK" FÜR BRENNER A25 ČIDLO "TK" PRO HOŘÁK A25
- J** MODUL AD03 FOR CONTROL COMPRESSOR FAN FROM BURNER A25/45 - PUMP RECONNECT FROM MODUL AD03 TO pos.7 MODUL AD03 FÜR BREMSKOMPRESSORBEDIENUNG UND KESSELVENTILATOR BEDIENUNG BEI DEM BRENNER A25/45 - ANSCHLUSS KESSELPUMPE VON MODUL AD03 AN KLEMMENLEISTE Pos.7 MODUL AD03 K OVLÁDÁNÍ KOMPRESORU A VENTILÁTORU KOTLE HOŘÁKEM A25/45 - ČERPADLO PŘEPOJENO Z MODULU AD03 DO SVORKOVNICE pos.7

**FOR BOILER:  
 FÜR KESSEL:  
 PRO KOTLE:**

- D20P, P20
- D30P, P30
- D31P, P31
- D40P, P40
- D50P, P50


IF IS PNEUMATIC CLEANER INSTALLED TO THE BURNER A25/45 THAN MUST BE FAN WIRING CONNECT TO POINT nr.12  
 WIEN DIE INSTALIERTE LUFTREINIGUNG FÜR BRENNER A25/45 SO ELEKTRISCHE PHASE FAN AN KLEMME nr. 12  
 POKUD JE INSTALOVÁNO PNEUMATICKÉ ČISTĚNÍ HOŘÁKU A25/45, MUSÍ BYT FÁZE VENTILÁTORU ZAPOJENA NA SVORKU č.12

EN


**BOILERS WITH FAN:  
KESSEL MIT GEBLÄSE:  
KOTLE S VENTILÁTOREM:**



**ELECTRIC DIAGRAM OF BRENNER A25-45 BEFORE IN-BUILDING PNEUMATIC CLEARING  
BRENNER A25-45 LEITUNGSSCHEMA VOR PNEUMATICREINIGUNGSMONTAGE  
ELEKTRICKÉ SCHÉMA HOŘÁKU A25-45 PŘED VESTAVBOU PNEUMATICKÉHO ČIŠTĚNÍ**




**ELECTRIC DIAGRAM OF BRENNER A25-45 AFTER IN-BUILDING PNEUMATIC CLEARING  
BRENNER A25-45 LEITUNGSSCHEMA DANN PNEUMATICREINIGUNGSMONTAGE  
ELEKTRICKÉ SCHÉMA HOŘÁKU A25-45 PO VESTAVBĚ PNEUMATICKÉHO ČIŠTĚNÍ**



- i.** RECONNECT GRAY KABEL FROM POSITION NR.9 TO MODUL AD04-LA  
DEN GRAU KABEL ABKLEMMEN AUS DEM POSITION N.9 ZU MODUL AD04-LA  
PŘEPOJENÝ ŠEDÝ VODIČ Z POZICE Č.9 DO MODULU AD04-LA
- ii.** CONNECT BROWN KABEL (PNEUMATIC VENTIL) TO POSITION NR.9  
DEN BRAUN KABEL (PNEUMATICVENTIL) KLEMMEN IN POSITION N.9  
ZAPOJIT HNĚVÝ VODIČ (PNEUMATICKÝ VENTIL) DO POZICE Č.9
- iii.** CONNECT BROWN KABEL (PNEUMATIC VENTIL) TO POSITION NR.8  
DEN BLAU KABEL (PNEUMATICVENTIL) KLEMMEN IN POSITION N.8  
PŘIPOJIT MODRÝ VODIČ (PNEUMATICKÝ VENTIL) DO POZICE Č.8
- iiii.** MODUL AD04 - CONNECT BLACK KABEL TO POSITION NR.13 AND GREY KABEL TO POSITION NR.15  
MODUL AD04 - DEN SCHWARZ KABEL KLEMMEN IN POSITION N.13 UND GRAU KABEL KLEMMEN IN POSITION N.15  
MODUL AD04 - PŘIPOJIT ČERNÝ VODIČ DO POZICE Č.13 A ŠEDÝ VODIČ DO POZICE Č.15

EN

# Wiring diagram for combined boilers for wood gasification and pellet burning DC18SP, DC25SP, DC30SPX, DC32SP, C18SP, C25SP, KC25S



**NOTES:**  
**POZNÁMKY:**


- A VARIANTS OF RESERVOIR POINTS "REG L,N,PE" (FERRULE/FASTON 6,3) FOR ELECTRONIC REGULATION (ACD01,ACD03,ACD04)  
SPRISKLEHMVARIANTEN "REG L,N,PE" (ADERENDHULSE/FASTON 6,3) FÜR ELEKTRONISCHE REGULATION (ACD01,ACD03,ACD04)  
VARIANTI NABĚRÁČEK SVORKY "REG L,N,PE" (DŮTKNÁK/FASTON 6,3) PRO ELEKTRONICKOU REGULACI (ACD01,ACD03,ACD04)
- B RESERVOIR POINT "L-FAN-IN" AND "L-FAN-OUT" OF BOILER FAN TO THE ELECTRONIC REGULATION (ACD01,ACD03,ACD04)  
SPRISKLEHM "L-FAN-IN" UND "L-FAN-OUT" DER KESSELGEHÄUSE FÜR DIE ELEKTRONISCHE REGULATION (ACD01,ACD03,ACD04)  
PŘIPOJOVACÍ SVORKA "L-FAN-IN" A "L-FAN-OUT" KOTLOVĚHO VENTILÁTORU DO ELEKTRONICKE REGULACE (ACD01,ACD03,ACD04)
- C RESERVOIR POINT "L-PUMP" OF BOILER PUMP TO THE ELECTRONIC REGULATION (ACD01,ACD03,ACD04)  
SPRISKLEHM "L-PUMP" DER KESSELPUMPE FÜR DIE ELEKTRONISCHE REGULATION (ACD01,ACD03,ACD04)  
PŘIPOJOVACÍ SVORKA "L-PUMP" KOTLOVĚHO ČERPADLA DO ELEKTRONICKE REGULACE (ACD01,ACD03,ACD04)
- D RESERVOIR POINT "L2-OUT" OF BURNER TO THE ELECTRONIC REGULATION (ACD01,ACD03,ACD04)  
SPRISKLEHM "L2-OUT" DER BRENNER FÜR DIE ELEKTRONISCHE REGULATION (ACD01,ACD03,ACD04)  
PŘIPOJOVACÍ SVORKA "L2-OUT" HOŘÁKU DO ELEKTRONICKE REGULACE (ACD01,ACD03,ACD04)
- E WHEN ELECTRONIC REGULATION (ACD01,ACD03,ACD04) CONTROL BURNER AND FAN - CONNECTORS "PT-C" AND "PT-1" MUST BE UNCONNECTED  
DEN KONNEKTOREN "PT-C" UND "PT-1" ABKLEMMEN BEI DER BRENNERBEDIENUNG UND KESSELGÄHÄUSEBEDIENUNG DER ELEKTRONISCHEN REGULATION (ACD01,ACD03,ACD04)  
KONEKTORY "PT-C" A "PT-1" ODPOJIT PŘI OVLÁDÁNÍ HOŘÁKU A VENTILÁTORU KOTLE ELEKTRONICKOU REGULACÍ (ACD01,ACD03,ACD04)
- F BOILER FAN CONNECTION - PLUS "SP-SP" BETWEEN "VVP2-1/VVP2-2" IS CONNECT ONLY WITH FUNCTION "AUTOSTART" IN BURNER ATMOS.  
KLEMMEN KESSEL FAN - KLEMMEN "SP-SP" ZWISCHEN "VVP2-1/VVP2-2" IST VERBUNDEN NUR MIT FUNKTION "AUTOSTART" IN BRENNER ATMOS.  
KLEMMEN VENTILÁTORU KOTLE - PŘIPOJKA "SP-SP" MEZI "VVP2-1/VVP2-2" JE ZAPOJENO POUZE S FUNKCÍ "AUTOSTART" V HOŘÁKU ATMOS.
- G WHEN ELECTRONIC REGULATION (ACD01,ACD03,ACD04) CONTROL BOILER PUMP - CONNECTORS "ST-2C" AND "ST-2Z" MUST BE UNCONNECTED  
DEN KONNEKTOREN "ST-2C" UND "ST-2Z" ABKLEMMEN BEI DER KESSELPUMPEBEDIENUNG DER ELEKTRONISCHEN REGULATION (ACD01,ACD03,ACD04)  
KONEKTORY "ST-2C" A "ST-2Z" ODPOJIT PŘI OVLÁDÁNÍ ČERPADLA KOTLE ELEKTRONICKOU REGULACÍ (ACD01,ACD03,ACD04)
- H WHEN ELECTRONIC REGULATION (ACD01,ACD03,ACD04) CONTROL BOILER FAN - CONNECTORS "ST-1C" AND "ST-1Z" MUST BE UNCONNECTED  
DEN KONNEKTOREN "ST-1C" UND "ST-1Z" ABKLEMMEN BEI DER KESSELGÄHÄUSEBEDIENUNG DER ELEKTRONISCHEN REGULATION (ACD01,ACD03,ACD04)  
KONEKTORY "ST-1C" A "ST-1Z" ODPOJIT PŘI OVLÁDÁNÍ VENTILÁTORU KOTLE ELEKTRONICKOU REGULACÍ (ACD01,ACD03,ACD04)
- I DEN KONNEKTORY "TCS" ABKLEMMEN BEI DER KESSELPUMPEBEDIENUNG DER ELEKTRONISCHEN REGULATION (ACD01,ACD03,ACD04)  
KONEKTORY "TCS" ODPOJIT PŘI OVLÁDÁNÍ ČERPADLA KOTLE ELEKTRONICKOU REGULACÍ (ACD01,ACD03,ACD04)
- J SENSOR "TK" AND SENSOR "TSV" FOR BURNER A25-SP  
FÜHLER TK UND FÜHLER TSV FÜR BRENNER A25-SP  
ODDO "TK" A ČIDLO "TSV" PRO HOŘÁK A25-SP
- K CONTROL OF SERVO AIR FLAP VALVE: L-M3=R4 with burner A25-SP (with module AD04) / L-M3=L2 with burner A25 without module AD04 (DO NOT USE - COLLISION WITH FUNCTION "AUTOSTART")  
SERVOKLAPPEBEDIENUNG: L-M3=R4 mit Brenner A25-SP (mit Modul AD04) / L-M3=L2 mit Brenner A25 ohne Modul AD04 (NICHT VERWENDEN - KOLLISION MIT DER FUNKTION "AUTOSTART")  
OVLÁDÁNÍ SERVOKLAPKY: L-M3=R4 s hořákem A25-SP (s modulem AD04) / L-M3=L2 s hořákem A25 bez modulem AD04 (NEPŮŽÍVAT - KOLIZE S FUNKCÍ "AUTOSTART")
- L WHEN ELECTRONIC REGULATION (ACD01,ACD03,ACD04) CONTROL BOILER FAN - CABEL MUST BE UNCONNECTED  
KABEL ABKLEMMEN BEI DER KESSELGÄHÄUSEBEDIENUNG DER ELEKTRONISCHEN REGULATION  
KABEL ODPOJIT PŘI OVLÁDÁNÍ VENTILÁTORU KOTLE ELEKTRONICKOU REGULACÍ
- M WHEN ELECTRONIC REGULATION (ACD01,ACD03,ACD04) CONTROL BOILER PUMP - CABEL MUST BE UNCONNECTED  
KABEL ABKLEMMEN BEI DER KESSELPUMPEBEDIENUNG DER ELEKTRONISCHEN REGULATION (ACD01,ACD03,ACD04)  
KABEL ODPOJIT PŘI OVLÁDÁNÍ ČERPADLA KOTLE ELEKTRONICKOU REGULACÍ (ACD01,ACD03,ACD04)
- N MODUL AD03 FÜR CONTROL BOILERFAN AND BOILERPUMP FROM BURNER A25-SP  
MODUL AD03 FÜR BEDIENUNG KESSELGÄHÄUSE UND KESSELPUMPE BEI DEM BRENNER A25-SP  
MODUL AD03 K OVLÁDÁNÍ VENTILÁTORU A ČERPADLA KOTLE HOŘÁKEM A25-SP
- O SET DIP DIRECTION OF ROTATION ON SERVO AIR FLAP VALVE = 1  
STELLN DIP DIRECTION AUF DEM SERVOKLAPPE = 1  
NASTAVENÍ PŘEPÍNAČE SMYSLU OTÁČENÍ NA MOTORU SERVOKLAPKY = 1

19-01-01\_DCxSP\_A25-SP\_6P\_AD03\_PUMP


EN




**ELECTRIC DIAGRAM OF BRENNER A25-SP BEFORE IN-BUILDING PNEUMATIC CLEARING**  
**BRENNER A25-SP LEITUNGSSCHEMA VOR PNEUMATISCHREINIGUNGSMONTAGE**  
**ELEKTRICKÉ SCHÉMA HOŘÁKU A25-SP PŘED VESTAVBOU PNEUMATICKÉHO ČIŠTĚNÍ**



**ELECTRIC DIAGRAM OF BRENNER A25-SP AFTER IN-BUILDING PNEUMATIC CLEARING**  
**BRENNER A25-SP LEITUNGSSCHEMA NACH PNEUMATISCHREINIGUNGSMONTAGE**  
**ELEKTRICKÉ SCHÉMA HOŘÁKU A25-SP PO VESTAVBĚ PNEUMATICKÉHO ČIŠTĚNÍ**



# Wiring diagram for combined boilers for wood gasification and pellet burning DC25GSP, DC30GSP




**NOTES:**  
**POZNÁMKY:**


- A** VARIANTS OF RESERVOIR POINTS "REG\_L,N,PE" (FERRULE/FASTON 6,3) FOR ELECTRONIC REGULATION  
VARIANTY NAPÁČECÍCH SVORKŮ "REG\_L,N,PE" (DUTINKA/FASTON 6,3) PRO ELEKTRONICKOU REGULACI
- B** RESERVOIR POINT "L-FAN-IN" AND "L-FAN OUT" OF BOILER FAN TO THE ELECTRONIC REGULATION  
SPRISKELNĚ "L-FAN-IN" A "L-FAN OUT" DER KESSELGEBLÄSE FÜR DIE ELEKTRONISCHE REGELUNG
- C** RESERVOIR POINT "L-PUMP" OF BOILER PUMP TO THE ELECTRONIC REGULATION  
SPRISKELNĚ "L-PUMP" DER KESSELPUMPE FÜR DIE ELEKTRONISCHE REGELUNG
- D** RESERVOIR POINT "L3-OUT" OF BURNER TO THE ELECTRONIC REGULATION  
SPRISKELNĚ "L3-OUT" DER BRENNER FÜR DIE ELEKTRONISCHE REGELUNG
- E** RESERVOIR POINT "L4-3" OF SERVOFLAP TO THE ELECTRONIC REGULATION  
SPRISKELNĚ "L4-3" DER SERVOKLAPPE FÜR DIE ELEKTRONISCHE REGELUNG
- F** WHEN ELECTRONIC REGULATION CONTROL BURNER AND FAN - CONNECTORS "FT-C" AND "FT-L" MUST BE UNCONNECT  
DIE KÖNNENSTEN "FT-C" A "FT-L" ODPOJIT PŘI OVLÁDÁNÍ HOŘÁKŮ A VENTILÁTORŮ KOTLE ELEKTRONICKOU REGULACI
- G** BOILER FAN CONNECTION - PLUG "GSP/GSP" BETWEEN "VP2-1/VP2-2" IS CONNECT ONLY IN BOILERS DC25GSP,  
KLEINE KESSEL FAN - KLEMME "GSP/GSP" ZWISCHEN "VP2-1/VP2-2" IST NUR IN KESSEL DC25GSP VERBUNDEN.  
KLEINA VENTILÁTORŮ KOTLE - PŘIPOJKA "GSP/GSP" MEZI "VP2-1/VP2-2" JE ZAPOJENA POUZE V KOTLECH TYPŮ DC25GSP.
- H** WHEN ELECTRONIC REGULATION CONTROL BOILER PUMP - CONNECTORS "ST1-C" AND "ST1-L" MUST BE UNCONNECT  
DIE KÖNNENSTEN "ST1-C" UND "ST1-L" ABKLEHMEN BEI DER KESSELPUMPEBEDIENUNG DER ELEKTRONISCHE REGELUNG
- I** WHEN ELECTRONIC REGULATION CONTROL BOILER FAN - CONNECTORS "ST2-C" AND "ST2-L" MUST BE UNCONNECT  
DIE KÖNNENSTEN "ST2-C" UND "ST2-L" ABKLEHMEN BEI DER KESSELGEBLÄSEBEDIENUNG DER ELEKTRONISCHE REGELUNG
- J** WHEN ELECTRONIC REGULATION CONTROL BOILER SERVO AIR FLAP VALVE - CONNECTORS "ST2-C" AND "ST2-L" MUST BE UNCONNECT  
DIE KÖNNENSTEN "ST2-C" UND "ST2-L" ABKLEHMEN BEI DER KESSELSERVOKLAPPEBEDIENUNG DER ELEKTRONISCHE REGELUNG
- K** WHEN ELECTRONIC REGULATION CONTROL BOILER PUMP - CONNECTORS "TCS" MUST BE UNCONNECT  
DIE KÖNNENSTEN "TCS" ABKLEHMEN BEI DER KESSELPUMPEBEDIENUNG DER ELEKTRONISCHE REGELUNG
- L** SENSOR "TK" AND SENSOR "TSV" FOR BURNER A25-GSP  
FÜHLER "TK" A FÜHLER "TSV" PRO HOŘÁK A25-GSP
- M** MODUL ADD8 FOR CONTROL: SERVOKLAPPE GSP, BOILER FAN AND BOILER PUMP  
MODUL ADD8 ZUR REGELUNG: SERVOKLAPPE GSP, KESSELGEBLÄSE UND KESSELPUMPE
- N** OUTPUT "R" (GRAY CABLE) BE RECONNECT FROM POSITION N1,1 TO N1,3 (R3) - BOILER FAN CONTROL BY MODUL ADD4  
AUSGANG "R" (GRAU KABEL) MUŠI PŘEPOJIT Z POZICE N1,1 DO C,13 (R3) - OVLÁDÁNÍ VENTILÁTORŮ KOTLE Z MODULU ADD4
- O** "TRENNER UND ISOLIERT "R2" (RED CABLE) AND "L15" (ORANGE CABLE)  
"TRENNER UND ISOLIERT "R2" (ROT KABEL) UND "L15" (ORANGE KABEL)
- P** SET DIP DIRECTION OF SERVO SWITCH  
NASTAVENÍ PŘEPÍNAČE SMYSLU OTÁČENÍ NA MOTORU SERVOKLAPPE
- Q** MODUL ADD2 FOR COMPRESSORCONTROL - ORIGINAL BLACK WIRE "L1" REPLACED THE WIRES FROM THE COMPRESSOR  
MODUL ADD2 ZUR KOMPRESSORBEDIENUNG - ORIGINAL SCHWARZE DRAHT "L1" ERSETZT DIE DRÄHTE AUS DEN KOMPRESSOR
- R** SET DIP DIRECTION OF ROTATION ON SERVO AIR FLAP VALVE = 1  
STELLEN DIP DREHRICHTUNG AUF DER SERVOKLAPPE = 1

16-02-01\_DCxxGSP\_A25-GSP\_6P\_AD08

**ELECTRIC DIAGRAM OF BRENNER A25-GSP BEFORE IN-BUILDING PNEUMATIC CLEARING**  
**BRENNER A25-GSP LEITUNGSSCHEMA VOR PNEUMATISCHREINIGUNGSMONTAGE**  
**ELEKTRICKÉ SCHÉMA HOŘÁKU A25-GSP PŘED VESTAVBOU PNEUMATICKÉHO ČIŠTĚNÍ**




**ELECTRIC DIAGRAM OF BRENNER A25-GSP AFTER IN-BUILDING PNEUMATIC CLEARING**  
**BRENNER A25-GSP LEITUNGSSCHEMA DANN PNEUMATISCHREINIGUNGSMONTAGE**  
**ELEKTRICKÉ SCHÉMA HOŘÁKU A25-GSP PO VESTAVBĚ PNEUMATICKÉHO ČIŠTĚNÍ**



19-12-01\_DCxxGSP\_A25-GSP\_6P\_AD08\_AD02-PNEU - FT01.sch


# Wiring system for boiler running only on pellets without exhaust fan D10PX, PX10



**NOTES:  
NOTEN:  
POZNÁMKY:**

- A** VARIANTS OF RESERVOIR POINTS "REG L,N,PE" (FERRULE/FASTON 6,3) FOR ELECTRONIC REGULATION  
SPEISEKLEMMENVARIANTEN "REG L,N,PE" (ADRENHÜLSE/FASTON 6,3) FÜR ELEKTRONISCHE REGELUNG  
VARIANTY NÁKLADEK SVORKY "REG L,N,PE" (OUITKA/FASTON 6,3) PRO ELEKTRONICKOU REGULACI
- B** RESERVOIR POINT "L2 OUT" OF BURNER TO THE ELECTRONIC REGULATION (ACD01)  
SPEISEKLEMME "L2 OUT" DER BRENNER FÜR DIE ELEKTRONISCHE REGELUNG (ACD01)  
PŘIPOJOVACÍ SVORKA "L2 OUT" HOŘÁKU DO ELEKTRONICKÉ REGULACE (ACD01)
- C** RESERVOIR POINT "L PUMP" OF BOILER PUMP TO THE ELECTRONIC REGULATION (ACD01)  
SPEISEKLEMME "L PUMP" DER KESSELPUMPE FÜR DIE ELEKTRONISCHE REGELUNG (ACD01)  
PŘIPOJOVACÍ SVORKA "L PUMP" KOTLOVÉHO ČERPADLA DO ELEKTRONICKÉ REGULACE (ACD01)
- D** WHEN ELECTRONIC REGULATION CONTROL BURNER - CONNECTORS "PT-C" AND "PT-I" MUST BE UNCONNECT  
DEN KONNEKTOREN "PT-C" UND "PT-I" ABKLEMMEN BEI DER BRENNERBEDIENUNG DER ELEKTRONISCHE REGELUNG  
KONEKTORY "PT-C" A "PT-I" ODPOJIT PŘI OVLÁDÁNÍ HOŘÁKU ELEKTRONICKOU REGULACÍ
- E** CONTROL OF BOILER PUMP FROM BURNER A25: TC70=R2 / CONTROL OF BOILER PUMP ONLY FROM PUMP THERMOSTAT TC70: TC70=230V / CONTROL OF BOILER PUMP FROM ELECTRONIC REGULATOR: UNCONNECT CONNECTOR TC70  
KESSEL PUMPE BEDIENUNG BEI DER BRENNER A25 REGELUNG: TC70=R2 / KESSEL PUMPE BEDIENUNG NUR BEI DER PUMPE THERMOSTAT TC70: TC70=230V / KESSEL PUMPE BEDIENUNG BEI DER ELEKTRON. REGELUNG: DEN KONNEKTOREN TC70 ABKLEMMEN  
OVLÁDÁNÍ ČERPADLA KOTLE Z HOŘÁKU A25: TC70=R2 / OVLÁDÁNÍ ČERPADLA KOTLE POUZE TERMOSTATEM TC70: TC70=230V / OVLÁDÁNÍ ČERPADLA KOTLE Z ELEKTRONICKÉ REGULACE: ODPOJIT KONEKTOR TC70
- F** OUTPUT R2 OF THE BURNER A25 CONTROL OF BOILER PUMP: R2=TC70 / OUTPUT R2 OF THE BURNER A25 IS USED FOR OTHER CONTROL: R2=R2  
AUSGANG R2 VON BRENNER A25 STEUERT DIE KESSEL PUMPE: R2=TC70 / AUSGANG R2 VON BRENNER A25 IST FÜR DIE ANDERE STEUERUNG VERWENDET: R2=R2  
VÝSTUP R2 Z HOŘÁKU A25 OVLÁDÁ ČERPADLO KOTLE: R2=TC70 / VÝSTUP R2 Z HOŘÁKU A25 JE POUŽITA NA JINÉ OVLÁDÁNÍ: R2=R2
- G** 3P CONNECTOR WITH PLUG  
3P KONNEKTOR MIT KLEMME  
3P KONEKTOR S KLEMMOU
- H** SENSOR "TK" AND SENSOR "TSV" FOR BURNER A25  
KESEL WASSER FÜHLER "TK" UND KESSEL ABGAS FÜHLER "TSV" FÜR BRENNER A25  
ČIDLO "TK" A ČIDLO "TSV" PRO HOŘÁK A25


19-01-01\_PX10



16-12-01\_A25PX - FT01

19-12-01\_PX10\_PNEU - FT01.sch

# Wiring system for boiler running only on pellets with exhaust fan D15PX, D20PX, D25PX, PX15, PX20, PX25




**NOTES:**  
**POZNÁMKY:**


- A** VARIANTS OF RESERVOIR POINTS "REG L,N,PE" (FERRULE/FASTON 6,3) FOR ELECTRONIC REGULATION  
SPEISEKLEMMENVARIANTEN "REG L,N,PE" (ADERNHÜLSE/FASTON 6,3) FÜR ELEKTRONISCHE REGELUNG  
VARIANTY NÁKLAJEČÍCH SVORKŮ "REG L,N,PE" (OUITKA/FASTON 6,3) PRO ELEKTRONICKOU REGULACI
- B** RESERVOIR POINT "L2 OUT" OF BURNER AND FAN TO THE ELECTRONIC REGULATION (ACD01)  
SPEISEKLEMME "L2 OUT" DER BRENNER UND VENTILATOR FÜR DIE ELEKTRONISCHE REGELUNG (ACD01)  
PŘIPOJOVACÍ SVORKA "L2 OUT" HOŘÁKU A VENTILÁTORU DO ELEKTRONICKÉ REGULACE (ACD01)
- C** RESERVOIR POINT "L PUMP" OF BOILER PUMP TO THE ELECTRONIC REGULATION (ACD01)  
SPEISEKLEMME "L PUMP" DER KESSELpumpe FÜR DIE ELEKTRONISCHE REGELUNG (ACD01)  
PŘIPOJOVACÍ SVORKA "L PUMP" KOTLOVÉHO ČERPADLA DO ELEKTRONICKÉ REGULACE (ACD01)
- D** WHEN ELECTRONIC REGULATION CONTROL BURNER - CONNECTORS "PT-C" AND "PT-1" MUST BE UNCONNECT  
DEN KONNEKTOR "PT-C" UND "PT-1" ABKLEMMEN BEI DER BRENNERBEDIENUNG DER ELEKTRONISCHE REGELUNG  
KONEKTORY "PT-C" A "PT-1" ODPLOJIT PŘI OVLÁDÁNÍ HOŘÁKU ELEKTRONICKOU REGULACI
- E** CONTROL OF BOILER PUMP FROM BURNER A25: TC70=R2 / CONTROL OF BOILER PUMP ONLY FROM PUMP THERMOSTAT TC70: TC70=230V / CONTROL OF BOILER PUMP FROM ELECTRONIC REGULATOR: UNCONNECT CONNECTOR TC70  
KESSELpumpe BEDIENUNG BEI DER BRENNER A25 REGELUNG: TC70=R2 / KESSELpumpe BEDIENUNG NUR BEI DER PUMPE THERMOSTAT TC70: TC70=230V / KESSELpumpe BEDIENUNG BEI DER ELEKTRON. REGELUNG: DEN KONNEKTOR TC70 ABKLEMMEN  
OVLÁDÁNÍ ČERPADLA KOTLE Z HOŘÁKU A25: TC70=R2 / OVLÁDÁNÍ ČERPADLA KOTLE POUZE THERMOSTATEM TC70: TC70=230V / OVLÁDÁNÍ ČERPADLA KOTLE Z ELEKTRONICKÉ REGULACE: ODPLOJIT KONEKTOR TC70
- F** OUTPUT R2 OF THE BURNER A25 CONTROL OF BOILER PUMP: R2=TC70 / OUTPUT R2 OF THE BURNER A25 IS USED FOR OTHER CONTROL: R2=R2  
AUSGANG R2 VON BRENNER A25 STEUERT DIE KESSELpumpe: R2=TC70 / AUSGANG R2 VON BRENNER A25 IST FÜR DIE ANDERE STEUERUNG VERWENDET: R2=R2  
VÝSTUP R2 Z HOŘÁKU A25 OVLÁDÁ ČERPADLO KOTLE: R2=TC70 / VÝSTUP R2 Z HOŘÁKU A25 JE POUŽITA NA JINÉ OVLÁDÁNÍ: R2=R2
- G** 3P CONNECTOR WITH PLUG  
3P KONNEKTOR MIT KLEMMU
- H** SENSOR "TK" AND SENSOR "TSV" FOR BURNER A25  
KESSEL WASSER FÜHLER "TK" UND KESSEL ABGAS FÜHLER "TSV" FÜR BRENNER A25  
ČIDLO "TK" A ČIDLO "TSV" PRO HOŘÁK A25

19\_04\_01 - P15-25PX

BL-BLACK-SCHWARZ-ČERNÁ  
BU-BLUE-BLAU-MODRÁ  
GY-GREEN/YELLOW-GRÜN/GELB-ZELENO/ŽLUTÁ  
GR-GREY-GRAU-SĚDÁ  
BR-BROWN-BRAUNE-HNĚDÁ  
RE-RED-ROT-CERVENÁ  
W-WHITE-WEIS-BILÁ



# Wiring diagram for gasification boiler for wood, coal and briquettes equipped with exhaust fan with build-in burner in upper doors DCxxS(X), DCxxRS, CxxS(T), ACxxS, KCxxS - old version



WHEN USE ELECTRONIC REGULATION ACC01 AND PELLETBURNER A25-45 MUST BE THESE CHANGES OF WIRING:  
 BEI DER STEUERUNG DES KESSELBETRIEBES DER ELEKTRONISCHE REGELUNG ACC01 UND PELLETBURNER A25-45 MÜSSEN DIESE ÄNDERUNGEN MACHEN SEIN:  
 PŘI ZAJOENÍ ELEKTRONICKÉ REGULACE ACC01 A PELETTOVÉHO HOŘÁKU A25-45 PROVĚDTE TYTO ZMĚNY:


13-01-01\_DCxxS HORAK\_6P

- (A)** VARIANTS OF RESERVOIR POINTS "REG L,N,PE" (FERRULE/FASTON 6,3) FOR ELECTRONIC REGULATION  
 SPEISEKLEMMENVARIANTEN "REG L,N,PE" (ADERENDHÜLSE/FASTON 6,3) FÜR ELEKTRONISCHE REGELUNG  
 VARIANTY NÁPAJEČÍCH SVORK "REG L,N,PE" (DUTKÁNK/FASTON 6,3) PRO ELEKTRONICKOU REGULACI
- (B)** RESERVOIR POINT "L-PUMP" OF BOILERPUMP TO THE ELECTRONIC REGULATION  
 SPEISEKLEMME "L-PUMP" DER KESSELPUMPE FÜR DIE ELEKTRONISCHE REGELUNG  
 PŘIPOJOVACÍ SVORKA "L-PUMP" KOTLOVÉHO ČERPADLA DO ELEKTRONICKÉ REGULACE
- (C)** RESERVOIR POINT "L - FAN IN" AND "L - FAN OUT" OF BOILER FAN TO THE ELECTRONIC REGULATION  
 SPEISEKLEMME "L - FAN IN" AND "L - FAN OUT" DER KESSELGEBLÄSE FÜR DIE ELEKTRONISCHE REGELUNG  
 PŘIPOJOVACÍ SVORKA "L - FAN IN" A "L - FAN OUT" KOTLOVÉHO VENTILÁTORU DO ELEKTRONICKÉ REGULACE
- (D)** RESERVOIR POINT "L2" OF BURNER TO THE ELECTRONIC REGULATION (BY THE SOFTWARE VERSION OF ACC01 )  
 SPEISEKLEMME "L2" DER BRENNER FÜR DIE ELEKTRONISCHE REGELUNG (GEMÄß SOFTWARE VERSION ACC01)  
 PŘIPOJOVACÍ SVORKA "L2" HOŘÁKU DO ELEKTRONICKÉ REGULACE (PODLE VERZE SOFTWAREU ACC01)
- (E)** WHEN ELECTRONIC REGULATION CONTROL BOILER FAN/BURNER - CONNECTORS "PT-C" AND "PT-1" MUST BE UNCONNECT  
 DEN KONNEKTOREN "PT-C" UND "PT-1" ABKLEMMEN BEI DER KESSELGEBLÄSE/BRENNER BETEDIENUNG DER ELEKTRONISCHE REGELUNG  
 KONNEKTORY "PT-C" A "PT-1" ODPOJIT PŘI OVLÁDÁNÍ KOTLOVÉHO VENTILÁTORU/HOŘÁKU ELEKTRONICKOU REGULACI
- (F)** WHEN ELECTRONIC REGULATION CONTROL BOILER FAN/PELLETS BURNER - CHANGE CONNECTOR "BT-N1" FOR CONNECTOR "BT-N1 REG"  
 DEN AUSWECHSELN KONNEKT "BT-N1" FÜR KONNEKT "BT-N1 REG" BEI DER KESSELGÄBLÄSE/BRENNER BETEDIENUNG DER ELEKTRON. REG.  
 PŘEHODIT SVORKY "BT-N1" ZA "BT-N1 REG" PŘI OVLÁDÁNÍ KOTLOVÉHO VENTILÁTORU/HOŘÁKU ELEKTRONICKOU REGULACI
- (G)** WHEN ELECTRONIC REGULATION CONTROL BOILER FAN/BURNER/PUMP/ - CHANGE CONNECTOR "ST-2" TO CONNECTOR "ST-2 REG"  
 DEN AUSWECHSELN KONNEKTOR "ST-2" FÜR KONNEKT "ST-2 REG" BEI DER GÄBLÄSE/BRENNER/PUMPE BETEDIENUNG DER ELEKTRON. REGELUNG  
 PŘEHODIT SVORKY "ST-2" ZA "ST-2 REG" PŘI OVLÁDÁNÍ KOTLOVÉHO VENTILÁTORU/HOŘÁKU/ČERPADLA ELEKTRONICKOU REGULACI
- (H)** WHEN ELECTRONIC REGULATION CONTROL PELLETS BURNER - CHANGE CONNECTOR "L2" TO CONNECTOR "L2 REG"  
 DEN AUSWECHSELN KONNEKTOR "L2" FÜR KONNEKT "L2 REG" BEI DER BRENNER BETEDIENUNG DER ELEKTRON. REGELUNG  
 PŘEHODIT SVORKY "L2" ZA "L2 REG" PŘI OVLÁDÁNÍ PELETTOVÉHO HOŘÁKU ELEKTRONICKOU REGULACI
- (I)** MODUL AD03 FOR CONTROL COMPRESSOR FAN FROM BURNER A25/45  
 MODUL AD03 FÜR BREMSKOMPRESSORBEDIENUNG UND KESSELVENTILATOR BETEDIENUNG BEI DEM BRENNER A25/45  
 MODUL AD03 K OVLÁDÁNÍ KOMPRESSORU A VENTILÁTORU KOTLE HOŘÁKEM A25/45


<b>FOR BOILER:</b>
<b>FÜR KESSEL:</b>
<b>PRO KOTLE:</b>
- CxxS HORAK
- ACxxS HORAK
- KCxxS HORAK
- DCxxS HORAK
- DCxxSX HORAK
- KCxxS HORAK



**ELECTRIC DIAGRAM OF BRENNER A25-45 BEFORE IN-BUILDING PNEUMATIC CLEARING**  
**BRENNER A25-45 LEITUNGSSCHEMA VOR PNEUMATICREINIGUNGSMONTAGE**  
**ELEKTRICKÉ SCHÉMA HOŘÁKU A25-45 PŘED VESTAVBOU PNEUMATICKÉHO ČIŠTĚNÍ**




**ELECTRIC DIAGRAM OF BRENNER A25-45 AFTER IN-BUILDING PNEUMATIC CLEARING**  
**BRENNER A25-45 LEITUNGSSCHEMA DANN PNEUMATICREINIGUNGSMONTAGE**  
**ELEKTRICKÉ SCHÉMA HOŘÁKU A25-45 PO VESTAVBĚ PNEUMATICKÉHO ČIŠTĚNÍ**



- i. RECONNECT GRAY KABEL FROM POSITION NR.9 TO MODUL AD04-LA  
 DEN GRAU KABEL ABKLEMMEN AUS DEM POSITION NR.9 ZU MODUL AD04-LA  
 PŘEPOJENÝ ŠEDÝ VODIČ Z POZICE Č.9 DO MODULU AD04-LA
- ii. CONNECT BROWN KABEL (PNEUMATIC VENTIL) TO POSITION NR.9  
 DEN BRAUN KABEL (PNEUMATICKÝ VENTIL) KLEMMEN IN POSITION N.9  
 ZAPOJIT HNĚDÝ VODIČ (PNEUMATICKÝ VENTIL) DO POZICE Č.9
- iii. CONNECT BLAU KABEL (PNEUMATIC VENTIL) TO POSITION NR.8  
 DEN BLUE KABEL (PNEUMATICKÝ VENTIL) KLEMMEN IN POSITION N.8  
 PŘIPOJIT MODRÝ VODIČ (PNEUMATICKÝ VENTIL) DO POZICE Č.8
- iv. MODUL AD04 - CONNECT BLACK KABEL TO POSITION NR.13 AND GREY KABEL TO POSITION NR.15  
 MODUL AD04 - DEN SCHWÄRZ KABEL KLEMMEN IN POSITION N.13 UND GRAU KABEL KLEMMEN IN POSITION N.15  
 MODUL AD04 - PŘIPOJIT ČERNÝ VODIČ DO POZICE Č.13 A ŠEDÝ VODIČ DO POZICE Č.15

# Wiring diagram for gasification boiler for wood, coal and briquettes equipped with exhaust fan with build-in burner in upper doors DCxxS(X), DCxxRS, CxxS(T), ACxxS, KCxxS - Model from 2017 (2x AD03)



WHEN USING ELECTRONIC REGULATION ADD3 AND PELLET BURNER A25-45 MUST BE THESE CHANGES OF WIRING:  
 BEI DER STEUERUNG DES KESSELBETRIEBES DER ELEKTRONISCHE REGELUNG ADD3 UND PELLETBRENNER A25-45 MÜSSEN DIESE ÄNDERUNGEN MACHEN SIE:  
 PRI ZAPOJENÍ ELEKTRONICKÉ REGULACE ADD3 A PELETOVÉHO HOŘÁKU A25-45 PROVĚDTE TYTO ZMĚNY:

- A VARIANTS OF RESERVOIR POINTS "REG\_LN\_RE" (FERULE/FASTON 6.3) FOR ELECTRONIC REGULATION SPEISELEHMEN/ARIANTEN "REG\_LN\_RE" (ADREHNHÖLSE/FASTON 6.3) FÜR ELEKTRONISCHE REGELUNG VARIANTEN NARABEČNÍCH SVORKÁCH "REG\_LN\_RE" (DÜTIN/FASTON 6.3) PRO ELEKTRONICKOU REGULACI
- B RESERVOIR POINT "L-PUMP" OF BOILER PUMP TO THE ELECTRONIC REGULATION SPEISELEHMEN "L-PUMP" DER KESSELPUMPE FÜR DIE ELEKTRONISCHE REGELUNG PŘÍPOJNÝ BOD "L-PUMP" KOTLOVÉHO ČERPADLA DO ELEKTRONICKÉ REGULACE
- C RESERVOIR POINT "L-FAN-OUT" OF BOILER FAN TO THE ELECTRONIC REGULATION SPEISELEHMEN "L-FAN-OUT" DER KESSELGEBLÄSE FÜR DIE ELEKTRONISCHE REGELUNG PŘÍPOJNÝ BOD SVORKA "L-FAN-OUT" KOTLOVÉHO VENTILÁTORU DO ELEKTRONICKOU REGULACI
- D RESERVOIR POINT "L2-OUT" OF BURNER TO THE ELECTRONIC REGULATION SPEISELEHMEN "L2-OUT" DER BRENNER FÜR DIE ELEKTRONISCHE REGELUNG PŘÍPOJNÝ BOD SVORKA "L2-OUT" HOŘÁKU DO ELEKTRONICKOU REGULACI
- E RESERVOIR POINT "L-FAN-IN" OF BOILER FAN TO THE ELECTRONIC REGULATION SPEISELEHMEN "L-FAN-IN" DER KESSELGEBLÄSE FÜR DIE ELEKTRONISCHE REGELUNG PŘÍPOJNÝ BOD SVORKA "L-FAN-IN" KOTLOVÉHO VENTILÁTORU DO ELEKTRONICKOU REGULACI
- F WHEN ELECTRONIC REGULATION CONTROL BURNER AND FAN - CONNECTORS "P1-C" AND "P1-A" MUST BE UNCONNECTED DEN KONEKTORŮM "P1-C" A "P1-A" ABLEHMEN BEI DER BRENNERBEDIENUNG UND KESSELGEBLÄSEBEDIENUNG DER ELEKTRONIC REGULATION KONEKTORY "P1-C" A "P1-A" ODPLOJÍ PŘI OVLÁDÁNÍ HOŘÁKU A VENTILÁTORU KOTLE ELEKTRONICKOU REGULACI
- G WHEN ELECTRONIC REGULATION CONTROL BOILER PUMP - CONNECTORS "S1-C" AND "S1-2" MUST BE UNCONNECTED DEN KONEKTORŮM "S1-C" A "S1-2" ABLEHMEN BEI DER KESSELGEBLÄSEBEDIENUNG DER ELEKTRONIC REGULATION KONEKTORY "S1-C" A "S1-2" ODPLOJÍ PŘI OVLÁDÁNÍ VENTILÁTORU KOTLE ELEKTRONICKOU REGULACI
- H WHEN ELECTRONIC REGULATION CONTROL BOILER PUMP - CONNECTORS "S1-C" AND "S1-2" MUST BE UNCONNECTED DEN KONEKTORŮM "S1-C" A "S1-2" ABLEHMEN BEI DER KESSELPUMPEBEDIENUNG DER ELEKTRONIC REGULATION KONEKTORY "S1-C" A "S1-2" ODPLOJÍ PŘI OVLÁDÁNÍ ČERPADLA KOTLE ELEKTRONICKOU REGULACI
- I WHEN ELECTRONIC REGULATION CONTROL BOILER FAN - CHANGE CONNECTOR "B1-L" TO CONNECTOR "B1-L1" REG" DEN AUSWECHSELN "B1-L" Z "B1-L1" ZA "B1-L1" REG" PŘI OVLÁDÁNÍ KOTLOVÉHO VENTILÁTORU ELEKTRONICKOU REGULACI
- J MODUL ADD3-2 FÜR CONTROL BOILERFAN WITHOUT WASTEGAS THERMOSTAT IN POSITION (N) MODUL ADD3-2 FÜR BEDIENTUNG KESSELGEBLÄSE UND KESSELPUMPE OHNE RAUCHGASTHERMOSTAT IN POSITION (N) MODUL ADD3-2 K OVLÁDÁNÍ VENTILÁTORU A ČERPADLA KOTLE BEZ SPALINOVÉHO THERMOSTATU V POZICI (N)
- K WHEN ELECTRONIC REGULATION CONTROL BOILER PUMP - CONNECTORS "T05" MUST BE UNCONNECTED DEN KONEKTORŮM "T05" ABLEHMEN BEI DER KESSELPUMPEBEDIENUNG DER ELEKTRONIC REGULATION KONEKTORY "T05" ODPLOJÍ PŘI OVLÁDÁNÍ ČERPADLA KOTLE ELEKTRONICKOU REGULACI
- L WHEN ELECTRONIC REGULATION CONTROL BOILER PUMP - CABLE "R2" MUST BE UNCONNECTED FROM POS.5 KABEL "R2" AUS POS.5 TRENNER BEI DER KESSELPUMPEBEDIENUNG DER ELEKTRONIC REGULATION KABEL "R2" ODPLOJÍ Z POS.5 PŘI OVLÁDÁNÍ ČERPADLA KOTLE ELEKTRONICKOU REGULACI
- M SENSOR "TK" FOR BURNER A25 KESSEL WÄSSER BRENNER "TK" FÜR BRENNER A25 ČIDLO "TK" PRO HOŘÁK A25
- N RED CABLE "R2" FROM MODUL ADD3-2 PUMP CONTROL FROM POS.11 TERMINALS DISCONNECT AND INSULATE = PUMP IS NOT CONTROL FROM BURNER KOTLE KABEL "R2" AUS MODUL ADD3-2 PUMPEBEDIENUNG AUS POS.11 TERMINAL UND ISOLIEREN = PUMPE NICHT VON BRENNER GESTEUERT CEBYENY VODIC "R2" Z MODULU ADD3-2 K OVLÁDÁNÍ ČERPADLA Z POS.11 ZALOŽOVAT = ČERPADLO NENÍ Z HOŘÁKU OVLÁDÁNO
- O MODUL ADD3-2 FÜR CONTROL BOILERFAN AND BOILERPUMP FROM BURNER A25 MODUL ADD3-2 FÜR BEDIENTUNG KESSELGEBLÄSE UND KESSELPUMPE BEI DEM BRENNER A25 MODUL ADD3-2 K OVLÁDÁNÍ VENTILÁTORU A ČERPADLA KOTLE HOŘÁKEM A25
- P MODUL ADD3 FÜR CONTROL COMPRESSOR FROM BURNER A25/45 MODUL ADD3 FÜR BREMSKOMPRESSORBEDIENUNG BEI DEM BRENNER A25/45 MODUL ADD3 K OVLÁDÁNÍ KOMPRESSOR HOŘÁKEM A25/45

**FOR BOILER:  
 FÜR KESSEL:  
 PRO KOTLE:**


- CxxS HORAK
- KCxxS HORAK
- ACxxS HORAK
- DCxxS HORAK
- DCxxS HORAK
- DCxxRS HORAK

19-10-01\_D0xxS\_HORAK\_2AD03\_PUMP




**INFO** – when connecting the boiler with pneumatic burner cleaning the pump thermostat 70 °C is not normally disconnected. It serves to switch the pump in the boiler circle. Disconnection of the thermostat 70 °C is only possible if the additional thermostat is added on the outlet pipe from the boiler (set to 75 °C) and its parallel connection with the boiler flue gas thermostat.

**ELECTRIC DIAGRAM OF BRENNER A25-45 BEFORE IN-BUILDING PNEUMATIC CLEARING  
BRENNER A25-45 LEITUNGSSCHEMA VOR PNEUMATISCHREINIGUNGSMONTAGE  
ELEKTRICKÉ SCHÉMA HOŘÁKU A25-45 PŘED VESTAVBOU PNEUMATICKÉHO ČIŠTĚNÍ**



**ELECTRIC DIAGRAM OF BRENNER A25-45 AFTER IN-BUILDING PNEUMATIC CLEARING  
BRENNER A25-45 LEITUNGSSCHEMA DANN PNEUMATISCHREINIGUNGSMONTAGE  
ELEKTRICKÉ SCHÉMA HOŘÁKU A25-45 PO VESTAVBĚ PNEUMATICKÉHO ČIŠTĚNÍ**



- i.** RECONNECT GRAY KABEL FROM POSITION NR.9 TO MODUL AD04-LA  
DEN GRAU KABEL ABKLEMMEN AUS DEM POSITION N.9 ZU MODUL AD04-LA  
PŘEPOJENÝ ŠEDÝ VODIČ Z POZICE Č.9 DO MODULU AD04-LA
- ii.** CONNECT BROWN KABEL (PNEUMATIC VENTIL) TO POSITION NR.9  
DEN BRAUN KABEL (PNEUMATICVENTIL) KLEMMEN IN POSITION N.9  
ZAPOJIT HŘEDVÝ VODIČ (PNEUMATICKÝ VENTIL) DO POZICE Č.9
- iii.** CONNECT BLAU KABEL (PNEUMATIC VENTIL) TO POSITION NR.8  
DEN BLAU KABEL (PNEUMATICVENTIL) KLEMMEN IN POSITION N.8  
ZAPOJIT MODRÝ VODIČ (PNEUMATICKÝ VENTIL) DO POZICE Č.8
- iiii.** MODUL AD04 - CONNECT BLACK KABEL TO POSITION NR.13 AND GREY KABEL TO POSITION NR.15  
MODUL AD04 - DEN SCHWARZ KABEL KLEMMEN IN POSITION N.13 UND GRAU KABEL KLEMMEN IN POSITION N.15  
MODUL AD04 - PŘIPOJIT ČERNÝ VODIČ DO POZICE Č.13 A ŠEDÝ VODIČ DO POZICE Č.15

19-10-01\_DCxxS\_HORAK\_2AD03\_A25-45-PNEU\_AD03\_AD04.sch

EN

## Connecting boiler exhaust fan controls via special AD04 module built in to A25 or A45 pellet burner (not apply to DxxPX, PXxx)



**INFO** – The AD04 special module should be fitted onto the A25 or A45 pellet (except A25 burner for boilers DCxxGSP where the AD04 modul is already inbuild) burner only if the boiler is fitted with an exhaust fan. This module allows the boiler exhaust fan to be operated together with the burner fan regardless of its speed. This is managed without use of R or R2 reserves from the VV burner electronics terminal (15) (not apply to DxxPX, PXxx). For DxxPX and PXxx boilers is the pump in boiler circuit and exhaust fan of the boiler controlled directly from the burner with reserves R and R2 - factory connection - never change.



*Insert the AD04 module to the lower section of the burner so it does not obstruct the suction of combustion air into the burner and connect it according to the previous diagrams (except the A25 burner for boilers DCxxGSP where the AD04 modul is already inbuild)*



**INFO** - connect the **grey wire** previously disconnected from terminal R (9) to the AD04 module at LA position. If needed, the AD04 module can be affixed to the lower interior burner section (not apply to DxxPX, PXxx).




*Affix the pellet burner to the appropriate boiler and fully tighten*



*Connect the connecting cable with a 6-pin connector on both ends between the burner and boiler*

## Adjusting and connecting wiring in boiler (not apply to DxxPX, PXxx)



Remove the screws at the back of the boiler hood and take off the hood



**WARNING** – before performing this task, ensure the **boiler is disconnected from the electricity** (power connector on boiler hood disconnected).

### Connecting compressor control via AD02 or AD03 module built in to boiler. Connecting boiler exhaust fan control via AD03 module second terminal.




**INFO** - terminal R (9) on the **boiler terminal place** is used to communicate between the AD04 and AD03 module for controlling the boiler exhaust fan (except the A25 burner for boilers DCxxGSP), and terminal R2 (10) is used for controlling the compressor through the AD02 or AD03 module. specific boiler type to the boiler terminal plate (**not apply to DxxPX, PXxx**)



With the rear grommet, pull through the connecting cable ending on one side with two wires (black and brown) and on the other with a 3-pin connector (female) for connecting with the compressor and terminal for power supply to the compressor from the wall socket (**not apply to DxxPX, PXxx**)



Connect the wire leading from the AD02 or AD03 module according to the wiring diagram for the specific boiler type to the boiler terminal plate (**not apply to DxxPX, PXxx**)



Connect the wires (brown and black) from the connecting cable to the AD02 or AD03 module according to the wiring diagram for the specific boiler type



Return the back section of the machine hood to its place and fix securely



**INFO - Connect the black wire** disconnected from the boiler terminal plate originally for connecting the exhaust fan to the AD03 module to the LA terminal **(not apply to DxxPX, PXxx).**



**WARNING -** for combined boilers for wood gasification and pellet burning DC18SP, DC25SP, DC30SPX, DC32SP, C18SP, C25SP, KC25SP don't forget to **insert the special clamp** to the on-off switch to ensure the exhaust fan operates together with the pellet burner. **Without this clamp, the pneumatic burner cleaner should not be put into operation for these boilers.**



**WARNING –** When pneumatic cleaning is installed on the A25/45 burner must be on boilers D20P, D30P, D31P, D40P, D50P, P20, P30, P31, P40, P50 **the phase fan connected to the point nr.12**

### Compressor and solenoid valve (electrovalve) connection for boilers DxxPX, PXxx




Breaking out holes for bushings on the underside of the burner for DxxPX, PXxx boilers



Installation of bushings and cables pulling from the compressor and electrovalve to the burner for DxxPX, PXxx boilers



Connection of the compressor and solenoid valve (electrovalve) control to the AC07X-C additional module terminals for DxxPX and PXxx boilers, compressor - brown wire L to terminal R5 (1), black wire to the L terminal (2) electrovalve - brown wire L to terminal R6 (6), blue wire to terminal N (3)



An example of fixing the connection during installation of pneumatic cleaning of the pellet burner (connection of the burner and compressor) for DxxPX and PXxx boilers

EN

### Connecting the compressed air system



Take the connecting tube, screw it to the compressor and tighten fully




Take the other end of the connecting tube with the seal and carefully connect it to the complete screw fitting with solenoid




**INFO** – turn the solenoid with screw to a tight position so the tube isn't twisted and everything the set-up looks good, taking account of the position of the compressor in the boiler room.




**WARNING** – the compressor and tube should be located **sufficiently far from any heat sources** to ensure they are not damaged.



Connect the connecting cable with 3-pin connector to the compressor



Connecting cable with 3-pin connector (female) between the compressor, boiler (module ACD02/03 and wall socket 230 V / 50 Hz



Zapojíme propojovací kabel s 3-PIN konektorem do kompresoru - version for DxxPX, PXxx boilers with burner bushings



Connect the connecting cable to the wall socket, either directly or using a special timer with **8 A inductive load**.... code: S0090 (Note – cannot normally be bought in shops)



**WARNING** – the compressor must never be powered directly from the boiler.





*Photo of suction filter screwed onto compressor*



*Compressor set up beside boiler*



**INFO** – the compressor is supplied assembled, but after final assembly you will need to **screw on the suction filter**. The suction filter channel must always lead downwards. Clean the filter at least once a year (blow it out with compressed air).

## 5. Requirements for chimneys, flues and other boiler parts during operation with pneumatic burner cleaner

### Chimney

All requirements are identical to the requirements detailed in the boiler operation manual.

### Flue way duct

Principle requirements are identical to the requirements detailed in the boiler operation manual.

You should be aware, however, that during pneumatic cleaning of the burner, **expansion of compressed air takes place** in the burner and boiler combustion chamber. As such, you need to **secure the flue from falling out of the chimney** and falling from the boiler neck. The flue must be mechanically affixed to the boiler neck with a pin or screw. Similarly, other parts such as elbows or extensions should be **carefully secured** to each other at joints.

You should also ensure that **ash and dust is not blown out of flue duct joints between the boiler and chimney** during pneumatic cleaning. As such, all joints and flue outlets should be tightened with an aluminium strip, putty or other similar method.



*Securing the flue duct with a screw*



*Tightening the flue with an aluminium tape*



**WARNING** – When using draught limiter placed on the flue way between the boiler and the chimney is not permitted to use the type for the open double flap out of the flue way (explosive type) because of possible dusting into the boiler room. If required, install draught limiter into the cleaning hole at the foot of the chimney.

### tubing between burner and conveyor, pellet inlet pipe with rim

All joints on the tube and pellet inlet pipe to the burner must be carefully tightened so that no dust can fall from the pellets into the boiler space.

## Flaps for combustion air intake

For DCxxSP(X), CxxSP, KCxxSP combined boilers and DxxP, Pxx boilers purely for pellets which allow the burning of pieces of wood in an emergency, you should ensure that all apertures through which combustion air flows in heating with wood are closed during operation of burner with pneumatic cleaner.



*Closed flap for inflow of combustion air for DxxP, Pxx boiler*



*Tightened additional secondary air cap for DxxP, Pxx boiler*



*Closed flap for inflow of combustion air for DCxxSP(X), CxxSP, KCxxSP boilers - for models till 2018*



*Combustion air inlet for the boiler DCxxGSP closed automatically using Belimo actuator Boiler types DCxxSP(X) from year 2018*

For gasification boilers for wood, coal and briquettes with an in-built burner in the upper doors DCxxS(X), DCxxRS, CxxS(T), ACxxS, KCxxS you need to mount a closing mechanism (valve) under the regulating FR24 flap with controlled draft regulator which you should close when burning pellets so that no dirt can fall through the grille under the flap into the boiler space. When burning wood, coal or briquettes, the flap is open.



*Disassembling flap for combustion air inflow*



*Assembling valve under flap with grille*



*Closed valve and regulating flap when burning pellets*



*Open valve and regulating flap when burning with manually added fuel*



**WARNING** – any other apertures on the boiler which are used for taking out ash or cleaning the boiler **must be securely closed** so that dirt cannot escape into the boiler space.



**INFO** - Pneumatic burner cleaning is completely safe, since it is performed once the fuel has fully burnt. Nevertheless, do your utmost to ensure the boiler remains relatively clean.

### **Boiler exhaust fan, gasifier nozzle and gasifier grille**


The boiler exhaust fan ensures suction pressure un the combustion chamber when operating a pellet burner.

Its function is very important for boilers with in-built burners in upper doors **due to the narrower cross-sections in the gasifier nozzle and gasifier grille.**

**In this case, the exhaust fan must be constantly running when the pellet burner pusher fan is running.**



**WARNING** – for safety reasons, a special grille is supplied as an accessory in the set for boilers with in-built burners in upper doors, which prevents the blockage of gasifier nozzles and gasifier grille with ash clumps ejected from the pellet burner combustion chamber in pneumatic cleaning.



*Positioning special grille for gasifier nozzle for DCxxS(X) boiler*



*Positioning special grille for gasifier nozzle for DCxxRS boiler*



*CxxS(T), ACxxS, KCxxS boiler gasifier grille without special additional grille*



*Affixing sticker with important information (ATTENTION – During burner operation with pneumatic cleaning...)*



**WARNING** - remember you must regularly check and clean the upper boiler chamber so the flue gas outlet from the boiler is not blocked with particles and ash removed by pneumatic cleaning (gasifier nozzle, gasifier grille).

EN

## 6. Setting up the pneumatic burner cleaner

If you want to operate the pneumatic burner cleaner system, its operation must be set up on the AC07X burner electronic regulation.

Basic presets can be done by changing the profile in menu **PARAMETERS** at version of the AC10 version 0.31 and higher. With the burner ATMOS A25 change the profile from the profile **A25 (GSP)** to profile **A25(GSP)pneu**. With the burner ATMOS A45 change the profile from the profile **A45** to profile **A45pneu**. In earlier program versions make the setting separately for each parameters. **For DxxPX and PXxx boilers set A25PX pneu profile.**

Exact setting make according to the pellet type, see the table on page 48 - 49.



**INFO** - in case of lower program version of the older burner is recommended to send the electronics in to the ATMOS company, where will be instaled latest program version for free (valid for AC07X). **In the case that in older burner is electronics AC07 with only one reserve output is necessary to exchanged this electronics for new type AC07X with two reserve outputs.**



**WARNING** - **check and secure everything before operating** the pneumatic burner cleaner so that everything is properly connected and secured according to the operation manual.

### Setting parameters

• **parameter T5** – Rundown time of the fan after the STOP command - for optimal burning out of pellets in the combustion chamber ...(15 min) - **set to 25 - 35 min**

• **parameter S6** – determines function of first **reserve R** - added output

The first reserve R is used most commonly for controlling the boiler exhaust fan (S6 = 4), but in this case we use it for controlling the solenoid which releases compressed air into the burner combustion chamber (**not apply for DxxPX, PXxx - do not change for this boilers**).

Set S6 = 16

• **parameter S14** – determins function of second **reserve R2** - added output

The second reserve R2 is used most commonly for controlling the pump in the boiler circuit (S14 = 13), but in this case we use it to control the compressor via the AD02 or AD03 module (**not apply for DxxPX, PXxx - do not change for this boilers**).

Set S14 = 15



**INFO** - for standard setting when **parameter S1 is set to a value of 2**, you can connect an appliance of **maximum current 2.46 A (approx. 566 VA)** to R and R2 reserve terminals together.

When setting where **parameter S1 is set to a value of 4**, which means that at the start both ignition coils are run, you can connect an appliance of **maximum current 0.29 A (approx. 67 VA)** to R and R2 reserve terminals together.

**To activate the function you need to set the specific times and working number of cycles after which the burner is cleaned. Values in brackets are set by the manufacturer!**

• **parameter S41** – is the function for automatic burner cleaning with compressed air after a specific number of working cycles (burn-out). The function assumes use of both reserve outputs (S6 = 16, S14 = 15 (S67 = 15, S68 = 16 in case of AC07X-C module)) – non-standard function... **(4)**

a) **S41 = 1 to 9**... function where burner cleaning will take place only once, and after the set number of cycles have run (1, 2, 3, 4, 5, 6, 7, 8, 9 – number of cycles)

b) **S41 = 11 to 19**... function where burner cleaning will take place always twice in a row after the set number of cycles have run (11 = 1, 12 = 2, 13 = 3, 14 = 4, 15 = 5, 16 = 6, 17 = 7, 18 = 8, 19 = 9 – number of cycles) (from 1. 4. 2013)

If parameter S41 = 0 or 10, the function is switched off.

• **parameter S42** – is the function for automatic burner cleaning with compressed air after a specific period of operation time has passed (in one cycle). Once the subsequent working cycle has ended (burn-out), the burner tubing is cleaned. The function assumes use of both reserve outputs (S6 = 16, S14 = 15 (S67 = 15, S68 = 16 in case of AC07X-C module)) – non-standard function... **(6 hours)**

The value set is the actual time in hours.

• **parameter S43** – is the function for automatic burner cleaning with compressed air after a specific period of operation time has passed. Once the set time has passed, the burner immediately burns out (AUTOSTOP), it is cleaned and once again run. If required at all requirements for START are met. (regardless of S41 and S42 parameters). The function assumes use of both reserve outputs (S6 = 16, S14 = 15 (S67 = 15, S68 = 16 in case of AC07X-C module)) – non-standard function... **(12 hours)**

This is the sum of operating hours of all completed cycles.

The value set is the actual time in hours.

• **parameter S44** – is the function for the compressor for automatic burner cleaning with compressed air where this parameter sets the period the compressor is run for so that a sufficient amount of compressed air is ready (pressure, function S6 = 16) – non-standard function... **(2 min)**

The value set is the actual time in minutes.

• **parameter S45** – is the function for the solenoid for automatic burner cleaning with compressed air where this parameter sets the period the solenoid is open to ensure perfect cleaning of burner combustion chambers (function S14 = 15) – non-standard function... **(1 s)**

The value set is the actual time in seconds. Never set a lower value than 1 s.

• **parameter S58** – characterizes the amount of compressed air for the first pre-cleaning of the burner when installing pneumatic cleaning the burner. This is the time at which the partial filling compressor air tank for pre-cleaning of the burner ... **(6 s) - standardly do not change**

- **Parameter S67** - characterizes function of **R5 reserve** output similar with S6 and S14 parameters with installed AC07X-C additional module. Primary is this reserve used to control air pump for pellet burner pneumatic ash cleaning system S67 = 15.  
Function is only for DxxPX (PXxx) boilers or burners equipped with additional module AC07X-C, burner profile A25PX (A25PX pneu)..... (0)

Set S67 = 15

- **Parameter S68** - characterizes function of **R6 reserve** output similar with S6 and S14 parameters with installed AC07X-C additional module. Primary is this reserve used to control air pump for pellet burner pneumatic ash cleaning system S68 = 16.  
Function is only for DxxPX (PXxx) boilers or burners equipped with additional module AC07X-C, burner profile A25PX (A25PX pneu)..... (0)

Set S68 = 16

**Recommended parameter settings according to the quality of pellets - not apply for DxxPX, PXxx**

Pellet type and quality	T5	S6	S14	S41	S42	S43	S44	S45
Quality white pellets without bark which do not form ash clumps	25	16	15	8	24	32	1 *	1
Wooden pellets with small amount of bark which create ash clumps in about a week	25	16	15	8	24	32	1 *	1
Wooden pellets with large amount of bark, where ash clumps have to be removed once a day	25	16	15	4	6	12	1 *	1
Wooden pellets of worst quality where high ash clumps are created after two to three hours operation	25	16	15	1	2	3	1 *	1
Pneumatic cleaning setting when using weekly timer	25	16	15	1	4	5	1 *	1
When connection of the pneumatic cleaning of the burner with the original or other compressor (up to 10 l air tank) set S58 = 6 s. When connection to a central compressed air distribution with pressure reducing valve and air tank up to 10 l set S58 = 1 s.								

\* Applies for the supplied compressor that is part of the set.



**Recommended parameter settings according to the quality of pellets - for boilers DxxPX, PXXx**

Pellet type and quality	T5	S6	S14	S41	S42	S43	S44	S45	S67	S68
Quality white pellets without bark which do not form ash clumps	25	3	12	8	24	32	1 *	1	15	16
Wooden pellets with small amount of bark which create ash clumps in about a week	25	3	12	8	24	32	1 *	1	15	16
Wooden pellets with large amount of bark, where ash clumps have to be removed once a day	25	3	12	4	6	12	1 *	1	15	16
Wooden pellets of worst quality where high ash clumps are created after two to three hours operation	25	3	12	1	2	3	1 *	1	15	16
Pneumatic cleaning setting when using weekly timer	25	3	12	1	4	5	1 *	1	15	16
When connection of the pneumatic cleaning of the burner with the original or other compressor (up to 10 l air tank) set S58 = 6 s. When connection to a central compressed air distribution with pressure reducing valve and air tank up to 10 l set S58 = 1 s.										

\* Applies for the supplied compressor that is part of the set.



**INFO** - You should note the optimal pressure with which the burner should be cleaned. For the compressor which is supplied as part of the set, it is set to 5 – 8 bar (500 - 800 kPa). When connecting your own compressor or to a central compressed air system, **set initial pressure to 5 bar (500 kPa).**



**WARNING** – if you use the **special 8 A weekly timer** for directly control of the compressor according to time (note – cannot normally be bought in shops), parameter **S41 must always be set at 1 (S41 = 1)**. Set other parameters according to the final table row. On the timer, set which times it is allowed (forbidden) to use the pneumatic cleaner, e.g. at night. **You cannot forbid pneumatic cleaner operation in one go for periods greater than 12 hours.**



**WARNING** - The timer cannot be used if you want to burn pellets with a large amount of bark and dirt, as the combustion chamber has to be cleaned more often than once a day.



**WARNING** - to regulate and set the optimal amount of compressed air for pneumatic cleaning of the burner, **never use the solenoid opening time** which is directly set on the burner (**never change S45 parameter**).

## 7. Maintenance and cleaning of burner with combustion chamber pneumatic cleaner

Basic maintenance and cleaning of the pellet burner is described in the manual for the specific boiler and pellet burner. We want to draw attention to the most important points however!



**INFO - Pneumatic cleaning of the burner significantly extends the period between combustion chamber cleanings and reduces boiler heat exchanger clogging (tube sheet).** Nevertheless, the burner should be regularly checked and cleaned when necessary.

**Cleaning the burner combustion chamber**, specifically cleaning the aperture for combustion air inflow is undertaken **in dependence on the pellet quality and amount of additions in the pellets such as starch, cornflour and various wood glues.** These substances make **apertures for combustion air inflow grow, especially from the bottom of the combustion chamber.** The interval between combustion chamber cleanings is generally between 7 days and 4 months.



*Slightly clogged apertures in combustion chamber after 4 months of use*



*Example of cleaning the combustion chamber*

**Cleaning of the channels for compressed air inflow** to the combustion chamber is undertaken in dependence on the quality of pellets from once a month to once every 4 months.



*Slight clogging after 4 months of use*



*Example of cleaning the front part of the compressed air inflow channel*

Cleaning the burner interior space located under the pellet inlet tube to the burner is undertaken in dependence on the amount of dust in the pellets, from once a month to once a season.



*Clogging after 3 months use with crushed pellets with large amount of dust*




*Example of cleaning the space under the pellet inlet tube*

EN

As needed, but at least **once a season** blow out (vacuum up) space inside the burner.



**WARNING - electronic unit AC07X never cleaned mechanically.**



*Example of cleaning (blow out) space inside the burner. (without power!)  
Caution of possible condensate from the compressed air source*



*Example of cleaning (blow out) pressure fan impeller of the burner once a season*

**!POZOR - ATTENTION - ACHTUNG!**

Při provozu hořáku s pneumatickým čištěním je zakázáno otevírat jakákoliv dvířka nebo víčka bez vypnutí hlavního vypínače na kotli.

During burner operation with pneumatic cleaning is forbidden to open any doors or lids without turning off the main switch on the boiler.

Während Betrieb des Brenners mit pneumatischer Reinigung ist verboten die Tür oder Deckel zu öffnen - ohne Ausschalten des Hauptschalters am Kessel.

*Important warning stuck on boiler hood*

**Compressor maintenance**, specifically checking the amount of oil, is undertaken **once to twice a year** for oil-filled compressor variant.

The oil-free version of the compressor does not require checking the oil level.

In addition, depending on dust level in the boiler room **the compressor filter is cleaned once to twice a year** (blow it out with compressed air)

If the compressor is located in a very dusty environment, according to need.

Also once a year, check all tubing and connections so as no compressed air can escape.



**WARNING - The air receiver (compressed air container) is a pressuried container and must be regularly checked with regular services carried out on it in accordance with the law in force in your country.**



*Checking oil levels in compressor*



*Cleaning compressor filter*

## WARRANTY PROVISIONS

A25/A45 pneumatic burner cleaner

1. If you observe the method of use, operation and maintenance of this product described in this manual, we guarantee that the product will keep the properties described by relevant technical standards and conditions over the whole warranty period, this being within 24 months from the day of receipt of the appliance, and a max. 32 months from the date of sale of the product by the sales representative.
2. If a fault occurs with the product during the warranty period which was not caused by the user, the product will be repaired under the warranty free of charge for the customer.
3. The warranty period is extended by the time over which the product is repaired under warranty.
4. Repairs undertaken during the warranty period are claimed by the customer using our service operations.
5. The product warranty is only recognised where the equipment is assembled by a qualified person in accordance with standards in force and the operation manual. A requirement for any warranty to be recognised is the details on the company which performed the assembly being legibly and fully completed. If the product is damaged through poor assembly, costs associated will be borne by the company which performed the assembly.
6. The purchaser has been demonstrably informed of the use and operation of the product.
7. Repairs undertaken after the warranty period ends are also claimed by the customer using our service operations. In this case, the customer pays the cost of repair himself.
8. The user is required to observe the instructions in the Operation and Maintenance Manual. If the customer does not follow the Operation and Maintenance Manual instructions, is careless, or handles the product incorrectly, the warranty is void and the customer is required to pay for any repairs resulting from damage.

**Warranty and post-warranty repairs are performed by:**

- the company representing ATMOS in your country for your region
- the assembly company which installed the product
- Jaroslav Cankař a syn ATMOS,

**Velenského 487, 294 21 Bělá pod Bezdězem, Česká republika, Tel. +420 326 701 404**

